


**CONTENTS**  
**ÍNDICE**  
**INDEX**  
**INHALTSVERZEICHNIS**  
**INDICE**  
**СОДЕРЖАНИЕ**  
**目录**

**CONTENTS - ÍNDICE - INDEX - INHALTSVERZEICHNIS**  
**СОДЕРЖАНИЕ - INDICE - 索引**

<b>GARRETT</b>	<b>1-192</b>
<b>HITACHI</b>	<b>193-194</b>
<b>HOLSET</b>	<b>195-214</b>
<b>IHI</b>	<b>215-242</b>
<b>KKK</b>	<b>243-288</b>
<b>MITSUBISHI</b>	<b>289-308</b>
<b>SCHWITZER</b>	<b>309-318</b>
<b>TOYOTA</b>	<b>319-327</b>

**HOW TO USE THE CATALOGUE**  
 EXPLICACIÓN, MANEJO DEL CATÁLOGO  
 EXPLICATIONS, USAGE DU CATALOGUE  
 UNTERRICHT FÜR GEBRAUCH DES KATALOGS  
 EXPLICAÇÃO SOBRE A UTILIZAÇÃO DO CATÁLOGO

					
773721-5001		JTC11013		OP10102	
					
<b>TURBO CHARGER REFERENCE</b> REFERENCIA DE TURBO RÉFÉRENCE TURBO TURBOLADERNUMMER REFERÊNCIA DA TURBINA		<b>TURBO FITTING KIT</b> JUEGO DE REPARACIÓN TURBO TURBO KIT DE REPARATION TURBOLADER MONTAGESATZ JOGO DE JUNTAS DO TURBO		<b>OIL FEED PIPE</b> TUBO DE ENGRASE TUBE DE GRAISSAGE ÖLZULAUFLEITUNG TUBO DE GRAXA	
	<b>BOX Nr.</b> <b>BLOQUE No.</b> <b>BLOCK Nr.</b> <b>BLOCO No.</b>				<b>QR CODE</b> <b>CÓDIGO QR</b> <b>QR CODE</b> <b>QR-CODE</b> <b>QR CODE</b>

68

ISTRUZIONI PER USO DEL CATALOGO  
КАК ПОЛЬЗОВАТЬСЯ КАТАЛОГОМ - ПОЯСНЕНИЯ

目录注释与使用说明

شرح ، إستعمال الكاتالوج

<p>773721-5001</p> <p>68</p>	<p>JTC11013</p>		<p>OP10102</p>	

REFERENZE TURBOCOMPRESSORI  
артикул турбины  
涡轮增压器型号  
المرجعية توربو

BLOCCO No.  
БЛО  
组号  
مجموعة رقم

KIT GIARNIZIONI TURBO  
набор для ремонта турбины  
涡轮增压器修理包  
توربو كيت إصلاح

QR CODE  
QR-KOD  
QR码  
ريال قطري كود

TUBO ALIMENTAZIONE OLIO  
трубка для смазки  
机油油管  
أنبوب الشحوم

QR CODE  
QR-KOD  
QR码  
ريال قطري كود

# TRAINING & TECHNICAL ASSISTANCE DEPARTMENT

DEPARTAMENTO DE FORMACIÓN Y ASISTENCIA TÉCNICA  
DEPARTEMENT DE FORMATION ET ASSISTANCE TECHNIQUE  
TECHNISCHE UNTERSTÜTZUNG UND AUSBILDUNGABTEILUNG  
DEPARTAMENTO DO FORMAÇÃO Y ASSISTENCIA TÉCNICA  
ОТДЕЛ ОБУЧЕНИЯ И ТЕХНИЧЕСКОЙ ПОДДЕРЖКИ

培训和技術支持部門

+34 - 967 216 212 (Albacete - España)

e-mail: [customerservice@ajusa.es](mailto:customerservice@ajusa.es)



## Worldwide Headquarters

Parque Empresarial Ajusa, Calle 1, nº 1 - CM 332, Km. 2,2 - 02006 ALBACETE (Spain)

Apdo. / P.O. Box 415 (02080)

Tel: +34 - 967 216 212 - Fax: +34 - 967 216 214 - 967 240 499 - e-mail: [ajusa@ajusa.es](mailto:ajusa@ajusa.es)



Brazil

## Ajusa Brazil

Rua Conselheiro Amaral, 90 - Vila Jaguara - Cep 05116-80 - SAO PAULO, SP (Brasil)

Tel: +55(11) 3622 5353 - Fax: +55(11) 3622 5353 - e-mail: [ajusadobrasil@ajusa.com.br](mailto:ajusadobrasil@ajusa.com.br)

[www.ajusa.com.br](http://www.ajusa.com.br)



Russia

## Ajusa Russia

p/o Voskresenskoe, a/ya. 19 - Leninsky rayon - 142791 Moscovskaya oblast (Russia)

Tel: + 7 (495) 741-79 73 - Tel / Fax: + 7 (495) 933-80 11 - e-mail: [ajusa@inbox.ru](mailto:ajusa@inbox.ru)

[www.ajusa.ru](http://www.ajusa.ru)



Mexico

## Ajusa Mexico

Calle Lago Ladoga, 295-A - Colonia Anahuac, Deleg. Miguel Hidalgo

MÉXICO, D.F. CP 11320 (México)

Tel / Fax: + 52 - 55 5254 2332 - e-mail: [ajusamexico@ajusa.com.mx](mailto:ajusamexico@ajusa.com.mx)

[www.ajusa.com.mx](http://www.ajusa.com.mx)



Northamerica

## Ajusa Northamerica

Partnership CRP Industries Inc

35 Commerce Drive - Cranbury, NJ 08512 - Toll Free 800 526-4066

Tel: 609 578-4100 - Fax: 609 655-5300 - e-mail: [info@crpindustries.com](mailto:info@crpindustries.com)

[www.ajusaparts.com](http://www.ajusaparts.com)



[www.ajusa.es](http://www.ajusa.es)



**AJUSA**

**1 edition**



**TURBO COMPONENTS CATALOG**  
by turbo model



***GARRETT***

				
402910-5032	JTC11144			
406076-5019	JTC11219			
408110-5005	JTC11120			
408110-5006	JTC11120			
408970-5002	JTC11065			
409200-5013	JTC11066			
409250-5002	JTC11067			
409300-5011	JTC11068			
409300-5026	JTC11068			
409410-5002	JTC11121			
409410-5006	JTC11121			



		
409410-5007	JTC11121	
409410-5008	JTC11121	
409410-5011	JTC11121	
409570-5010	JTC11315	
409570-5016	JTC11315	
409710-5001	JTC11106	
409760-5002	JTC11315	
409770-5018	JTC11315	
409770-5019	JTC11315	
409770-5025	JTC11315	
409840-5005	JTC11070	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
409930-5003	JTC11148			
422979-5003	JTC11364			
433076-5019	JTC11219			
434251-5041	JTC11219			
452005-5001	JTC11061			
452014-5006	JTC11225			
452022-5001	JTC11312			
452024-5003	JTC11092			
452038-5002	JTC11083			
452047-5001	JTC11122			
452047-5002	JTC11122			

		
452055-5004	JTC11206	
452055-5008	JTC11206	
452058-5002	JTC11282	
452059-5001	JTC11072	
452060-5001	JTC11073	
452061-5005	JTC11003	
452062-5003	JTC11074	
452063-5002	JTC11226	
452065-5002	JTC11003	
452065-5003	JTC11003	
452068-5001	JTC11437	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
452068-5002	JTC11437			
452068-5003	JTC11437			
452068-5004	JTC11437			
452069-5001	JTC11147			
452069-5002	JTC11147			
452070-5001	JTC11123			
452070-5002	JTC11123			
452070-5003	JTC11123			
452070-5004	JTC11123			
452070-5007	JTC11123			
452070-5009	JTC11123			

		
452070-5010	JTC11123	
452070-5011	JTC11123	
452070-5012	JTC11123	
452070-5013	JTC11123	
452070-5014	JTC11123	
452073-5001	JTC11003	
452073-5002	JTC11003	
452073-5003	JTC11003	
452073-5004	JTC11003	
452073-5005	JTC11003	
452073-5006	JTC11003	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

452075-5001	JTC11283			
452076-5003	JTC11175			
452077-5004	JTC11050			
452083-5001	JTC11003			
452084-5004	JTC11022			
452084-5007	JTC11022			
452084-5009	JTC11022			
452084-5011	JTC11022			
452085-5004	JTC11039		OP10088	
452088-5001	JTC11147			
452098-5001	JTC11083			

		
452098-5002	JTC11083	
452098-5004	JTC11083	
452101-5001	JTC11186	
452101-5002	JTC11186	
452109-5001	JTC11284	
452109-5002	JTC11284	
452109-5003	JTC11284	
452109-5004	JTC11284	
452109-5005	JTC11284	
452109-5006	JTC11284	
452109-5007	JTC11284	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

452109-5008	JTC11284			
452109-5010	JTC11284			
452123-5001	JTC11318			
452124-5004	JTC11318			
452124-5006	JTC11022			
452129-5001	JTC11075			
452129-5002	JTC11075			
452129-5003	JTC11075			
452134-5001	JTC11285			
452134-5002	JTC11285			
452151-5002	JTC11124			



		
452151-5004	JTC11124	
452162-5001	JTC11220	
452164-5001	JTC11212	
452164-5003	JTC11212	
452164-5004	JTC11212	
452164-5006	JTC11212	
452164-5007	JTC11212	
452164-5010	JTC11212	
452164-5011	JTC11212	
452164-5012	JTC11212	
452164-5013	JTC11212	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

452164-5014	JTC11212			
452164-5015	JTC11212			
452164-5016	JTC11212			
452164-5017	JTC11212			
452164-5019	JTC11212			
452165-5001	JTC11217			
452165-5002	JTC11217			
452165-5003	JTC11217			
452173-5001	JTC11125			
452174-5001	JTC11076			
452174-5002	JTC11076			



		
452174-5003	JTC11076	
452174-5007	JTC11076	
452174-5010	JTC11076	
452187-5001	JTC11077	
452187-5003	JTC11077	
452187-5006	JTC11077	
452194-5001	JTC11287	
452195-5003	JTC11004	
452202-5003	JTC11004	
452202-5004	JTC11004	
452203-5001	JTC11317	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
452203-5002	JTC11317			
452204-5001	JTC11029			
452204-5003	JTC11029			
452204-5004	JTC11029			
452204-5005	JTC11029			
452204-5007	JTC11029		OP10108	
452207-5007	JTC11105			
452213-5001	JTC11081			
452213-5002	JTC11081			
452213-5003	JTC11081			
452214-5003	JTC11372			

					
452215-5002	JTC11316				
452229-5001	JTC11209				
452229-5002	JTC11209				
452232-5001	JTC11211				
452232-5005	JTC11211				
452232-5007	JTC11211				
452232-5008	JTC11211				
452232-5009	JTC11211				
452232-5010	JTC11211				
452232-5011	JTC11211				
452232-5013	JTC11211				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
452232-5014	JTC11211			
452232-5015	JTC11211			
452232-5016	JTC11211			
452232-5017	JTC11211			
452232-5018	JTC11211			
452232-5021	JTC11211			
452233-5002	JTC11319			
452233-5004	JTC11319			
452234-5001	JTC11319			
452234-5003	JTC11319			
452234-5006	JTC11319			



		
452235-5001	JTC11209	
452235-5002	JTC11209	
452235-5003	JTC11209	
452235-5007	JTC11209	
452235-5008	JTC11209	
452235-5009	JTC11209	
452239-5003	JTC11337	
452239-5005	JTC11337	
452239-5006	JTC11337	
452239-5008	JTC11337	
452239-5009	JTC11337	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

452244-5005	JTC11322			
452274-5004	JTC11445			
452274-5005	JTC11445			
452274-5006	JTC11445			
452281-5001	JTC11321			
452281-5004	JTC11321			
452281-5006	JTC11321			
452281-5008	JTC11321			
452281-5009	JTC11321			
452281-5010	JTC11321			
452281-5012	JTC11321			



		
452281-5013	JTC11321	
452281-5014	JTC11321	
452281-5016	JTC11321	
452281-5017	JTC11321	
452281-5018	JTC11321	
452283-5001	JTC11320	
452283-5002	JTC11320	
452283-5003	JTC11320	
452308-5001	JTC11211	
452308-5002	JTC11211	
452308-5003	JTC11284	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
452308-5004	JTC11284			
452308-5005	JTC11284			
452308-5007	JTC11284			
452308-5008	JTC11284			
452308-5009	JTC11284			
452308-5010	JTC11284			
452308-5011	JTC11284			
452308-5012	JTC11284			
452308-5013	JTC11284			
452308-5014	JTC11284			
452308-5015	JTC11284			



					
452308-5016	JTC11284				
452308-5017	JTC11284				
452308-5018	JTC11284				
452308-5019	JTC11284				
452308-5020	JTC11284				
452309-5001	JTC11284				
452309-5002	JTC11284				
452309-5003	JTC11284				
452309-5004	JTC11284				
452309-5005	JTC11284				
452309-5006	JTC11284				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
452309-5008	JTC11284			
452309-5009	JTC11284			
452309-5010	JTC11284			
452309-5011	JTC11284			
452309-5012	JTC11284			
452309-5013	JTC11284			
452309-5014	JTC11284			
452309-5015	JTC11284			
452309-5016	JTC11284			
452309-5017	JTC11284			
452309-5018	JTC11284			



		
452311-5001	JTC11211	
452311-5003	JTC11211	
452311-5004	JTC11211	
452311-5005	JTC11211	
452311-5006	JTC11211	
452311-5007	JTC11211	
452311-5008	JTC11211	
452311-5009	JTC11211	
452312-5001	JTC11211	
452312-5002	JTC11211	
452312-5003	JTC11211	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
452312-5004	JTC11211			
452312-5006	JTC11211			
452312-5007	JTC11211			
452312-5008	JTC11284			
452312-5009	JTC11284			
452315-5001	JTC11211			
452315-5002	JTC11211			
452315-5003	JTC11211			
452315-5004	JTC11211			
452315-5005	JTC11211			
452315-5006	JTC11211			

		
452315-5007	JTC11211	
452315-5008	JTC11211	
452315-5009	JTC11211	
452315-5010	JTC11211	
452315-5011	JTC11211	
452315-5012	JTC11211	
452315-5013	JTC11211	
454001-5001	JTC11126	
454002-5001	JTC11048	
454003-5001	JTC11123	
454003-5002	JTC11123	




Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
454003-5003	JTC11123			
454003-5004	JTC11123			
454003-5005	JTC11123			
454003-5006	JTC11123			
454003-5007	JTC11123			
454003-5008	JTC11219			
454003-5009	JTC11123			
454003-5011	JTC11123			
454003-5012	JTC11123			
454006-5002	JTC11062			
454006-5004	JTC11062			



					
454007-5001	JTC11078				
454007-5002	JTC11078				
454007-5003	JTC11078				
454007-5004	JTC11078				
454007-5005	JTC11078				
454007-5006	JTC11078				
454007-5007	JTC11078				
454007-5008	JTC11078				
454023-5002	JTC11079				
454027-5001	JTC11215				
454027-5002	JTC11215				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

454039-5001	JTC11323			
454041-5001	JTC11127			
454047-5001	JTC11080			
454052-5001	JTC11080			
454052-5002	JTC11423			
454054-5001	JTC11003			
454054-5002	JTC11003			
454055-5001	JTC11056		OP10101	
454055-5002	JTC11056			
454059-5004	JTC11325			
454061-5010	JTC11015			

					
454061-5014	JTC11015				
454064-5001	JTC11005				
454065-5002	JTC11006				
454067-5001	JTC11061				
454067-5002	JTC11061				
454076-5001	JTC11326				
454076-5002	JTC11326				
454080-5004	JTC11062				
454082-5001	JTC11082				
454082-5002	JTC11082				
454083-5001	JTC11004				

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
454083-5002	JTC11004			
454086-5001	JTC11215			
454086-5006	JTC11215			
454087-5003	JTC11326			
454092-5001	JTC11138			
454093-5001	JTC11042			
454093-5002	JTC11042			
454093-5003	JTC11042			
454093-5004	JTC11042			
454093-5006	JTC11042			
454096-5001	JTC11327			

		
454097-5001	JTC11006	
454097-5002	JTC11006	
454098-5001	JTC11028	
454098-5002	JTC11028	
454098-5003	JTC11028	
454110-5001	JTC11007	
454110-5002	JTC11007	
454111-5001	JTC11007	
454112-5003	JTC11326	
454112-5004	JTC11326	
454112-5005	JTC11326	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.



454127-5001	JTC11188			
454127-5002	JTC11188			
454131-5002	JTC11215			
454132-5001	JTC11215			
454132-5002	JTC11215			
454135-5001	JTC11013		OP10068	
454135-5002	JTC11013		OP10068	
454135-5003	JTC11013			
454135-5005	JTC11013		OP10068	
454135-5006	JTC11013		OP10068	
454135-5008	JTC11013		OP10068	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

454135-5009	JTC11013	OP10068
454135-5010	JTC11013	OP10067 (SEE APPLICATION CATALOGUE BY MODEL)  OP10068 (SEE APPLICATION CATALOGUE BY MODEL)  OP10069 (SEE APPLICATION CATALOGUE BY MODEL)
454145-5002	JTC11188	
454145-5003	JTC11188	
454150-5003	JTC11044	
454150-5004	JTC11044	
454150-5005	JTC11044	
454150-5006	JTC11044	
454154-5001	JTC11003	
454155-5002	JTC11189	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

454156-5001	JTC11188			
454158-5001	JTC11021			
454158-5003	JTC11021			
454158-5004	JTC11021			
454159-5001	JTC11083			
454159-5002	JTC11083			
454161-5001	JTC11008		<p>OP10045 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10048 (SEE APPLICATION CATALOGUE BY MODEL)</p>	
454161-5003	JTC11008		<p>OP10045 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10048 (SEE APPLICATION CATALOGUE BY MODEL)</p>	
454161-5004	JTC11008			
454162-5001	JTC11024			



		
454163-5001	JTC11084	
454163-5002	JTC11084	
454164-5002	JTC11190	
454164-5004	JTC11190	
454171-5001	JTC11008	
454171-5004	JTC11008	
454171-5005	JTC11224	
454172-5001	JTC11004	
454172-5002	JTC11004	
454176-5005	JTC11195	
454176-5006	JTC11195	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

454183-5001	JTC11008		OP10047	
454183-5002	JTC11008			
454183-5003	JTC11008		OP10047	
454183-5004	JTC11008		OP10047	
454183-5005	JTC11008			
454187-5001	JTC11085			
454191-5003	JTC11026			
454191-5004	JTC11026			
454191-5005	JTC11026			
454191-5006	JTC11026			
454191-5007	JTC11026			

454191-5008	JTC11026	
454191-5009	JTC11026	OP10035 
454191-5010	JTC11026	
454191-5011	JTC11026	
454191-5012	JTC11026	OP10035 
454191-5013	JTC11026	
454191-5015	JTC11026	OP10035 
454191-5017	JTC11026	
454192-5001	JTC11013	
454192-5002	JTC11013	
454192-5005	JTC11013	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
454192-5006	JTC11013			
454193-5001	JTC11007			
454193-5002	JTC11007			
454193-5003	JTC11007			
454193-5004	JTC11007			
454197-5001	JTC11045			
454197-5002	JTC11045			
454197-5003	JTC11045			
454203-5001	JTC11007			
454203-5002	JTC11007			
454204-5001	JTC11326			

		
454204-5002	JTC11326	
454205-5001	JTC11241	
454205-5006	JTC11241	
454207-5001	JTC11007	
454207-5002	JTC11007	
454216-5001	JTC11028	
454216-5002	JTC11028	
454216-5003	JTC11028	
454219-5001	JTC11043	
454219-5002	JTC11043	
454219-5003	JTC11043	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

454219-5004	JTC11043			
454229-5001	JTC11138			
454229-5002	JTC11138			
454231-5001	JTC11008		<p><b>OP10044</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10046</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10082</b> (SEE APPLICATION CATALOGUE BY MODEL)</p>	
454231-5002	JTC11008		OP10082	
454231-5003	JTC11008		<p><b>OP10044</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10046</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10082</b> (SEE APPLICATION CATALOGUE BY MODEL)</p>	

		
454231-5004	JTC11008	 <p>OP10044 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10046 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10082 (SEE APPLICATION CATALOGUE BY MODEL)</p>   
454231-5005	JTC11008	 <p>OP10044 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10046 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10082 (SEE APPLICATION CATALOGUE BY MODEL)</p>   
454231-5006	JTC11008	
454231-5007	JTC11008	 <p>OP10044 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10046 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10082 (SEE APPLICATION CATALOGUE BY MODEL)</p>   
454231-5008	JTC11008	
454231-5009	JTC11008	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.



454231-5010	JTC11008		<p>OP10060 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10082 (SEE APPLICATION CATALOGUE BY MODEL)</p>	
454231-5012	JTC11008			
454231-5013	JTC11008			
454232-5001	JTC11020		<p>OP10010 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10053 (SEE APPLICATION CATALOGUE BY MODEL)</p>	
454232-5002	JTC11020		<p>OP10010 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10053 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10057 (SEE APPLICATION CATALOGUE BY MODEL)</p>	
454232-5003	JTC11020			
454232-5004	JTC11020		<p>OP10010 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10053 (SEE APPLICATION CATALOGUE BY MODEL)</p>	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
All kits include the necessary components for one turbocharger.  
Scan QR code for a real picture of the product and technical tips.



454232-5005	JTC11020	<p>OP10010 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10053 (SEE APPLICATION CATALOGUE BY MODEL)</p>
454232-5006	JTC11020	<p>OP10010 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10053 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10057 (SEE APPLICATION CATALOGUE BY MODEL)</p>
454232-5011	JTC11020	<p>OP10010 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10053 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10057 (SEE APPLICATION CATALOGUE BY MODEL)</p>
454232-5014	JTC11020	
465044-5225	JTC11147	
465044-5227	JTC11147	
465044-5234	JTC11147	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
465044-5251	JTC11147			
465044-5252	JTC11147			
465044-5257	JTC11147			
465044-5261	JTC11147			
465048-5001	JTC11262			
465048-5002	JTC11262			
465048-5003	JTC11262			
465048-5004	JTC11262			
465048-5005	JTC11262			
465048-5006	JTC11262			
465048-5007	JTC11262			



		
465048-5011	JTC11262	
465048-5012	JTC11262	
465070-5010	JTC11135	
465088-5001	JTC11121	
465103-5001	JTC11086	
465103-5002	JTC11086	
465103-5003	JTC11086	
465103-5004	JTC11086	
465103-5005	JTC11086	
465103-5006	JTC11086	
465103-5007	JTC11086	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
465103-5009	JTC11086			
465105-5002	JTC11087			
465105-5003	JTC11129			
465114-5005	JTC11147			
465115-5001	JTC11147			
465133-5003	JTC11009			
465137-5001	JTC11060			
465137-5002	JTC11060			
465153-5003	JTC11472			
465153-5004	JTC11472			
465154-5001	JTC11064			



		
465154-5005	JTC11088	
465154-5014	JTC11088	
465154-5026	JTC11088	
465163-5001	JTC11089	
465165-5001	JTC11090	
465171-5002	JTC11061	
465175-5001	JTC11091	
465177-5005	JTC11148	
465181-5002	JTC11003	
465183-5007	JTC11003	
465186-5001	JTC11092	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
465189-5001	JTC11093			
465189-5003	JTC11093			
465198-5001	JTC11094			
465198-5003	JTC11094			
465199-5003	JTC11130			
465204-5001	JTC11095			
465209-5002	JTC11328			
465209-5003	JTC11328			
465209-5004	JTC11328			
465209-5005	JTC11328			
465209-5006	JTC11328			

		
465218-5001	JTC11094	
465218-5002	JTC11094	
465218-5007	JTC11094	
465228-5003	JTC11098	
465247-5001	JTC11542	
465265-5001	JTC11096	
465265-5002	JTC11096	
465283-5001	JTC11216	
465283-5002	JTC11216	
465283-5003	JTC11216	
465288-5001	JTC11092	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
465288-5003	JTC11065			
465296-5004	JTC11097			
465296-5005	JTC11097			
465318-5002	JTC11097			
465318-5003	JTC11098			
465318-5005	JTC11098			
465318-5006	JTC11098			
465318-5008	JTC11098			
465318-5009	JTC11098			
465318-5010	JTC11098			
465343-5001	JTC11329			

		
<p>465355-5001</p>	<p>JTC11131</p>	
<p>465366-5007</p>	<p>JTC11039</p>	 <p>OP10073 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10074 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10075 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10076 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10077 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10078 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10079 (SEE APPLICATION CATALOGUE BY MODEL)</p> 

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.



			<p>465366-5007</p>	<p>JTC11039</p>		<p><b>OP10080</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10083</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10085</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10086</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10087</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10088</b> (SEE APPLICATION CATALOGUE BY MODEL)</p>	
<p>465366-5013</p>	<p>JTC11039</p>		<p><b>OP10073</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10074</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10075</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10076</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10077</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10078</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10079</b> (SEE APPLICATION CATALOGUE BY MODEL)</p>				

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.



<p>465366-5013</p>	<p>JTC11039</p>	<div data-bbox="847 342 983 472" data-label="Image"> </div> <div data-bbox="1059 342 1219 398" data-label="Text"> <p><b>OP10080</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 463 1219 519" data-label="Text"> <p><b>OP10083</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 584 1219 640" data-label="Text"> <p><b>OP10085</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 705 1219 761" data-label="Text"> <p><b>OP10086</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 826 1219 882" data-label="Text"> <p><b>OP10087</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 947 1219 1003" data-label="Text"> <p><b>OP10088</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1329 342 1465 1070" data-label="Image"> </div>
<p>465366-5017</p>	<p>JTC11039</p>	<div data-bbox="847 1097 983 1227" data-label="Image"> </div> <div data-bbox="1059 1097 1219 1153" data-label="Text"> <p><b>OP10073</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 1218 1219 1274" data-label="Text"> <p><b>OP10074</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 1339 1219 1395" data-label="Text"> <p><b>OP10075</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 1460 1219 1516" data-label="Text"> <p><b>OP10076</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 1581 1219 1637" data-label="Text"> <p><b>OP10077</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 1702 1219 1758" data-label="Text"> <p><b>OP10078</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 1823 1219 1879" data-label="Text"> <p><b>OP10079</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1329 1097 1465 1937" data-label="Image"> </div>



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
All kits include the necessary components for one turbocharger.  
Scan QR code for a real picture of the product and technical tips.

465366-5017	JTC11039		<p><b>OP10080</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10083</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10085</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10086</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10087</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10088</b> (SEE APPLICATION CATALOGUE BY MODEL)</p>	
465367-5001	JTC11061			
465375-5002	JTC11335			
465379-5003	JTC11128			
465384-5004	JTC11150			
465384-5005	JTC11059			
465403-5003	JTC11064			

		
465403-5004	JTC11064	
465407-5002	JTC11438	
465413-5004	JTC11064	
465425-5001	JTC11092	
465425-5002	JTC11092	
465427-5001	JTC11092	
465427-5002	JTC11092	
465427-5005	JTC11092	
465427-5007	JTC11092	
465429-5001	JTC11333	
465429-5002	JTC11333	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
465438-5005	JTC11332			
465439-5002	JTC11024			
465443-5001	JTC11092			
465443-5003	JTC11092			
465446-5001	JTC11099			
465447-5002	JTC11494			
465468-5005	JTC11147			
465468-5008	JTC11132			
465468-5009	JTC11147			
465468-5010	JTC11147			
465468-5013	JTC11147			



		
465468-5014	JTC11147	
465468-5021	JTC11100	
465468-5022	JTC11100	
465481-5001	JTC11101	
465481-5002	JTC11219	
465481-5003	JTC11219	
465489-5001	JTC11102	
465489-5002	JTC11102	
465489-5004	JTC11102	
465489-5005	JTC11102	
465493-5003	JTC11098	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

465512-5003	JTC11103			
465514-5004	JTC11104			
465547-5001	JTC11147			
465547-5002	JTC11147			
465547-5003	JTC11147			
465547-5004	JTC11147			
465547-5005	JTC11147			
465550-5003	JTC11116			
465553-5001	JTC11133			
465555-5002	JTC11026			
465555-5003	JTC11026		OP10033	



		
465563-5001	JTC11105	
465567-5002	JTC11443	
465570-5002	JTC11065	
465577-5001	JTC11002	
465587-5002	JTC11080	
465589-5001	JTC11230	
465590-5005	JTC11065	
465600-5001	JTC11064	
465600-5006	JTC11147	
465600-5010	JTC11064	
465610-5011	JTC11064	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
465614-5002	JTC11098			
465632-5007	JTC11128			
465636-5207	JTC11106			
465640-5013	JTC11064			
465640-5015	JTC11064			
465640-5020	JTC11064			
465640-5021	JTC11064			
465640-5022	JTC11064			
465640-5024	JTC11064			
465640-5026	JTC11064			
465740-5003	JTC11106			



		
465740-5005	JTC11106	
465744-5001	JTC11092	
465744-5004	JTC11092	
465752-5002	JTC11092	
465764-5002	JTC11107	
465774-5012	JTC11134	
465776-5001	JTC11108	
465776-5003	JTC11108	
465776-5005	JTC11108	
465776-5008	JTC11108	
465776-5011	JTC11108	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
465778-5004	JTC11092			
465778-5007	JTC11092			
465778-5008	JTC11092			
465778-5010	JTC11092			
465778-5015	JTC11092			
465778-5016	JTC11092			
465778-5017	JTC11092			
465778-5018	JTC11092			
465795-5004	JTC11000			
465820-5001	JTC11064			
465823-5002	JTC11054			



		
465896-5002	JTC11128	
465898-5001	JTC11147	
465904-5003	JTC11109	
465916-5001	JTC11072	
465916-5002	JTC11072	
465922-5015	JTC11146	
465941-5005	JTC11312	
465942-5001	JTC11212	
465942-5002	JTC11212	
465942-5003	JTC11212	
465942-5004	JTC11212	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
465942-5005	JTC11212			
465942-5006	JTC11212			
465942-5011	JTC11212			
465942-5012	JTC11212			
465942-5013	JTC11212			
465942-5014	JTC11212			
465942-5015	JTC11212			
465942-5016	JTC11212			
465960-5003	JTC11016			
465997-5004	JTC11000			
466007-5002	JTC11427			



		
466007-5003	JTC11427	
466007-5006	JTC11427	
466016-5002	JTC11009	
466016-5003	JTC11009	
466032-5001	JTC11147	
466032-5003	JTC11147	
466071-5002	JTC11336	
466076-5012	JTC11073	
466076-5014	JTC11073	
466076-5015	JTC11073	
466076-5016	JTC11073	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
466076-5018	JTC11073			
466076-5019	JTC11073			
466076-5020	JTC11073			
466076-5021	JTC11123			
466076-5022	JTC11123			
466076-5027	JTC11073			
466076-5029	JTC11073			
466076-5030	JTC11073			
466076-5031	JTC11073			
466076-5032	JTC11073			
466076-5033	JTC11123			



		
466088-5001	JTC11001	
466133-5003	JTC11009	
466194-5001	JTC11104	
466200-5011	JTC11076	
466214-5001	JTC11010	
466214-5002	JTC11010	
466214-5006	JTC11010	
466214-5007	JTC11010	
466214-5008	JTC11010	
466214-5009	JTC11010	
466214-5010	JTC11010	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
466214-5012	JTC11010			
466214-5014	JTC11010			
466214-5015	JTC11010			
466214-5019	JTC11010			
466214-5024	JTC11010			
466214-5025	JTC11010			
466214-5026	JTC11010			
466214-5028	JTC11010			
466214-5030	JTC11010			
466214-5032	JTC11010			
466214-5033	JTC11010			



		
466214-5036	JTC11010	
466214-5038	JTC11010	
466214-5039	JTC11010	
466242-5015	JTC11172	
466242-5016	JTC11172	
466242-5017	JTC11172	
466242-5019	JTC11172	
466272-5005	JTC11061	
466287-5005	JTC11053	
466334-5002	JTC11147	
466334-5004	JTC11147	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
466334-5008	JTC11147			
466346-5001	JTC11147			
466370-5023	JTC11061			
466384-5001	JTC11147			
466384-5003	JTC11147			
466384-5004	JTC11147			
466384-5006	JTC11089			
466384-5008	JTC11147			
466404-5002	JTC11018			
466420-5001	JTC11110			
466448-5001	JTC11147			

		
466450-5001	JTC11061	
466452-5001	JTC11061	
466456-5001	JTC11009	
466478-5012	JTC11208	
466501-5005	JTC11344	
466506-5005	JTC11061	
466506-5006	JTC11061	
466534-5003	JTC11002	
466534-5004	JTC11002	
466534-5005	JTC11002	
466541-5001	JTC11343	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
466541-5004	JTC11343			
466543-5001	JTC11000			
466588-5001	JTC11092			
466588-5003	JTC11092			
466588-5008	JTC11213			
466592-5011	JTC11123			
466592-5014	JTC11123			
466616-5001	JTC11135			
466616-5003	JTC11147			
466616-5007	JTC11115			
466618-5010	JTC11054			



				
466618-5013	JTC11054			
466618-5015	JTC11146			
466618-5017	JTC11054			
466628-5002	JTC11092			
466628-5004	JTC11092			
466644-5001	JTC11147			
466646-5013	JTC11116			
466646-5020	JTC11147			
466646-5025	JTC11039		<p>OP10080 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10088 (SEE APPLICATION CATALOGUE BY MODEL)</p>	 



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

466646-5034	JTC11039		<p><b>OP10085</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10086</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10087</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10088</b> (SEE APPLICATION CATALOGUE BY MODEL)</p>	
466652-5001	JTC11136			
466674-5001	JTC11009			
466674-5003	JTC11009			
466674-5004	JTC11009			
466674-5005	JTC11009			
466674-5007	JTC11009			
466676-5012	JTC11363			
466698-5001	JTC11117			

		
466698-5003	JTC11098	
466698-5004	JTC11098	
466698-5005	JTC11098	
466698-5006	JTC11098	
466698-5007	JTC11098	
466698-5008	JTC11098	
466722-5001	JTC11064	
466728-5001	JTC11061	
466742-5003	JTC11050	
466742-5004	JTC11050	
466742-5006	JTC11050	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
466742-5010	JTC11050			
466742-5012	JTC11050			
466742-5013	JTC11050			
466746-5001	JTC11092			
466746-5003	JTC11092			
466746-5004	JTC11092			
466746-5010	JTC11092			
466755-5002	JTC11003			
466755-5003	JTC11003			
466770-5001	JTC11061			
466770-5002	JTC11061			



					
466770-5003	JTC11061				
466770-5004	JTC11061				
466770-5005	JTC11061				
466770-5006	JTC11061				
466770-5008	JTC11061				
466778-5001	JTC11118				
466778-5004	JTC11118				
466780-5001	JTC11108				
466780-5002	JTC11108				
466780-5003	JTC11108				
466780-5004	JTC11108				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

466780-5005	JTC11108			
466780-5006	JTC11108			
466794-5001	JTC11011			
466794-5002	JTC11011			
466800-5001	JTC11089			
466800-5004	JTC11089			
466800-5005	JTC11089			
466818-5001	JTC11054			
466818-5003	JTC11137			
466828-5001	JTC11050			
466828-5002	JTC11050			



					
466828-5005	JTC11147				
466828-5006	JTC11147				
466828-5007	JTC11147				
466828-5008	JTC11147				
466828-5009	JTC11147				
466828-5010	JTC11147				
466854-5001	JTC11009				
466856-5001	JTC11111				
466856-5003	JTC11111				
466858-5001	JTC11440				
466880-5001	JTC11416				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
466880-5002	JTC11416			
466884-5002	JTC11112			
466932-5001	JTC11113			
466944-5001	JTC11093			
466948-5001	JTC11441			
466952-5005	JTC11178			
466954-5001	JTC11114			
466962-5001	JTC11093			
466974-5002	JTC11080			
466974-5003	JTC11080			
466974-5005	JTC11080			

		
466974-5006	JTC11080	
466974-5007	JTC11080	
466974-5008	JTC11080	
466974-5009	JTC11080	
466974-5010	JTC11080	
468186-5000	JTC11253	
468187-5000	JTC11254	
468188-5000	JTC11255	
468189-5000	JTC11256	
468190-5000	JTC11120	
468191-5000	JTC11257	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
468192-5000	JTC11258			
468462-5000	JTC11259			
471037-5002	JTC11344			
471050-5001	JTC11334			
471050-5002	JTC11334			
471050-5003	JTC11334			
471050-5009	JTC11334			
471050-5025	JTC11334			
471050-5026	JTC11427			
471050-5027	JTC11334			
471171-5003	JTC11343			



		
471171-5009	JTC11343	
479034-5001	JTC11123	
479034-5003	JTC11123	
700273-5001	JTC11196	
700273-5002	JTC11196	
700382-5003	JTC11340	
700382-5007	JTC11340	
700447-5001	JTC11026	
700447-5003	JTC11026	
700447-5004	JTC11026	
700447-5005	JTC11026	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

700447-5006	JTC11026			
700447-5007	JTC11026			
700447-5008	JTC11026		OP10034	
700447-5009	JTC11026			
700467-5001	JTC11386			
700625-5001	JTC11197			
700625-5002	JTC11197			
700716-5003	JTC11562			
700716-5005	JTC11562			
700716-5007	JTC11562			
700716-5009	JTC11562			



		
700716-5011	JTC11562	
700716-5012	JTC11562	
700716-5014	JTC11562	
700716-5017	JTC11562	
700716-5018	JTC11562	
700716-5020	JTC11562	
700830-5001	JTC11017	
700830-5003	JTC11017	
700917-5001	JTC11344	
700935-5001	JTC11026	
700935-5003	JTC11026	OP10035 



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
700935-5004	JTC11026			
700935-5006	JTC11026			
700935-5007	JTC11026			
700960-5001	JTC11247			
700960-5002	JTC11247			
700960-5003	JTC11247			
700960-5004	JTC11247			
700960-5005	JTC11247			
700960-5008	JTC11247			
700960-5011	JTC11247			
700960-5012	JTC11247			

		
700999-5001	JTC11062	
701072-5001	JTC11189	
701164-5002	JTC11246	
701196-5007	JTC11311	
701370-5001	JTC11062	
701729-5001	JTC11004	
701729-5003	JTC11004	
701729-5006	JTC11004	
701729-5009	JTC11004	
701729-5010	JTC11004	
701796-5001	JTC11062	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
701854-5002	JTC11012			
701854-5003	JTC11012			
701854-5004	JTC11012			
701854-5005	JTC11012			
701855-5001	JTC11012			
701855-5002	JTC11012		OP10047	
701855-5005	JTC11012			
701855-5006	JTC11012			
701855-5007	JTC11012			
701855-5008	JTC11012			
701900-5001	JTC11044			



		
701900-5002	JTC11044	
702021-5001	JTC11433	
702339-5001	JTC11062	
702404-5002	JTC11238	
702637-5001	JTC11346	
702989-5003	JTC11389	
702989-5006	JTC11389	
703072-5001	JTC11284	
703072-5002	JTC11284	
703072-5003	JTC11284	
703072-5004	JTC11314	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

703325-5001	JTC11314			
703389-5002	JTC11344			
703672-5001	JTC11042			
703672-5002	JTC11042			
703672-5003	JTC11042			
703672-5004	JTC11042			
703672-5005	JTC11042			
703673-5001	JTC11026			
703673-5002	JTC11026		OP10036	
703673-5003	JTC11026			
703673-5004	JTC11026		OP10036	



		
703673-5005	JTC11026	
703674-5001	JTC11083	
703753-5001	JTC11242	
703863-5002	JTC11023	
703894-5003	JTC11342	
704059-5001	JTC11025	
704205-5001	JTC11341	
704205-5002	JTC11341	
704226-5007	JTC11023	
704226-5010	JTC11046	
704361-5004	JTC11042	OP10035 



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
704361-5005	JTC11042		OP10035	
704361-5006	JTC11042		OP10035	
704361-5010	JTC11042			
704487-5001	JTC11045			
705097-5001	JTC11342			
705097-5002	JTC11342			
705204-5001	JTC11345			
705204-5002	JTC11345			
705306-5001	JTC11313			
705306-5002	JTC11313			
705306-5006	JTC11313			



		
705306-5007	JTC11313	
705330-5001	JTC11235	
705954-5002	JTC11388	
705954-5003	JTC11388	
705954-5004	JTC11388	
705954-5006	JTC11388	
705954-5007	JTC11388	
705954-5008	JTC11388	
705954-5009	JTC11388	
705954-5010	JTC11388	
705954-5011	JTC11388	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
705954-5012	JTC11388			
705954-5013	JTC11388			
705954-5014	JTC11388			
705954-5015	JTC11388			
706120-5001	JTC11442			
706499-5001	JTC11023			
706499-5002	JTC11023			
706499-5004	JTC11023			
706680-5001	JTC11004			
706705-5001	JTC11319			
706712-5001	JTC11021			

		
706844-5001	JTC11208	
706844-5002	JTC11208	
706844-5003	JTC11208	
706844-5004	JTC11208	
706844-5005	JTC11208	
706844-5006	JTC11208	
706844-5007	JTC11208	
706844-5008	JTC11208	
706844-5009	JTC11208	
706858-5001	JTC11121	
706860-5001	JTC11008	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
706976-5001	JTC11202			
706976-5002	JTC11202			
706977-5001	JTC11202			
706977-5002	JTC11202			
706977-5003	JTC11202			
706978-5001	JTC11205			
707106-5001	JTC11349			
707106-5004	JTC11349			
707160-5005	JTC11336			
707160-5007	JTC11336			
707160-5009	JTC11336			

				
707160-5010	JTC11336			
707240-5001	JTC11276		OP10126	
707240-5002	JTC11276		OP10126	
707240-5003	JTC11276		OP10126	
707240-5004	JTC11276		OP10126	
707240-5005	JTC11276		OP10126	
707906-5006	JTC11608			
707906-5007	JTC11608			
708016-5001	JTC11126			
708016-5002	JTC11126			
708116-5001	JTC11045			

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

708163-5001	JTC11015			
708366-5001	JTC11026			
708366-5002	JTC11026			
708366-5003	JTC11026			
708366-5004	JTC11026			
708366-5005	JTC11026		OP10099	
708366-5006	JTC11026			
708366-5007	JTC11026			
708613-5001	JTC11023			
708618-5004	JTC11046			
708618-5005	JTC11046			

			<p>708618-5006</p>	<p>JTC11046</p>			
<p>708618-5007</p>	<p>JTC11046</p>						
<p>708618-5009</p>	<p>JTC11046</p>						
<p>708618-5011</p>	<p>JTC11046</p>						
<p>708639-5002</p>	<p>JTC11037</p>		<p><a href="#">OP10022</a> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><a href="#">OP10032</a> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><a href="#">OP10094</a> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><a href="#">OP10095</a> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><a href="#">OP10096</a> (SEE APPLICATION CATALOGUE BY MODEL)</p>				

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

708639-5003	JTC11037		<p><b>OP10022</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10032</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10094</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10095</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10096</b> (SEE APPLICATION CATALOGUE BY MODEL)</p>	
708639-5004	JTC11037			
708639-5005	JTC11037		<p><b>OP10022</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10032</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10094</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10095</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10096</b> (SEE APPLICATION CATALOGUE BY MODEL)</p>	

<p>708639-5006</p>	<p>JTC11037</p>	<div data-bbox="847 342 983 472" data-label="Image"> </div> <div data-bbox="1059 338 1219 398" data-label="Text"> <p><b>OP10022</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 461 1219 521" data-label="Text"> <p><b>OP10032</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 584 1219 645" data-label="Text"> <p><b>OP10094</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 707 1219 768" data-label="Text"> <p><b>OP10095</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 831 1219 891" data-label="Text"> <p><b>OP10096</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1329 342 1465 943" data-label="Image"> </div>
<p>708639-5007</p>	<p>JTC11037</p>	<div data-bbox="847 978 983 1108" data-label="Image"> </div> <div data-bbox="1059 974 1219 1034" data-label="Text"> <p><b>OP10022</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 1097 1219 1158" data-label="Text"> <p><b>OP10032</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 1220 1219 1281" data-label="Text"> <p><b>OP10094</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 1344 1219 1404" data-label="Text"> <p><b>OP10095</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 1467 1219 1527" data-label="Text"> <p><b>OP10096</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1329 978 1465 1579" data-label="Image"> </div>
<p>708639-5008</p>	<p>JTC11037</p>	<div data-bbox="847 1615 983 1744" data-label="Image"> </div>

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
All kits include the necessary components for one turbocharger.  
Scan QR code for a real picture of the product and technical tips.

708639-5010	JTC11037		<p><b>OP10022</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10032</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10094</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10095</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10096</b> (SEE APPLICATION CATALOGUE BY MODEL)</p>	
708639-5011	JTC11037			
708699-5001	JTC11347			
708699-5002	JTC11347			
708837-5001	JTC11027			
708847-5001	JTC11062			
708847-5002	JTC11062			
708866-5002	JTC11028			



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

708867-5002	JTC11028			
709035-5004	JTC11046			
709035-5005	JTC11023			
709377-5003	JTC11315			
709574-5001	JTC11284			
709574-5002	JTC11284			
709574-5003	JTC11284			
709574-5004	JTC11284			
709693-5001	JTC11352			
709835-5001	JTC11016		<p>OP10090 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10092 (SEE APPLICATION CATALOGUE BY MODEL)</p>	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

709835-5002	JTC11016		<p>OP10090 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10092 (SEE APPLICATION CATALOGUE BY MODEL)</p>	
709835-5003	JTC11016			
709836-5001	JTC11016		<p>OP10017 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10090 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10092 (SEE APPLICATION CATALOGUE BY MODEL)</p>	
709836-5003	JTC11016			
709836-5004	JTC11016		<p>OP10017 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10090 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10092 (SEE APPLICATION CATALOGUE BY MODEL)</p>	
709836-5005	JTC11016			
709837-5001	JTC11016			

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

		
709837-5002	JTC11016	OP10092
709837-5003	JTC11016	
709838-5001	JTC11016	OP10017
709838-5003	JTC11016	
709838-5004	JTC11016	
709838-5005	JTC11016	OP10017
709838-5006	JTC11016	
709841-5001	JTC11016	OP10093
709841-5002	JTC11016	OP10093
709841-5003	JTC11016	
709942-5008	JTC11319	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

710060-5001	JTC11421			
710060-5003	JTC11421		OP10129	
710415-5001	JTC11026			
710415-5003	JTC11026		OP10035	
710415-5007	JTC11026			
710811-5001	JTC11145			
710811-5002	JTC11145			
710812-5001	JTC11145			
710812-5002	JTC11145			
711006-5001	JTC11016		OP10090 (SEE APPLICATION CATALOGUE BY MODEL)  OP10092 (SEE APPLICATION CATALOGUE BY MODEL)	



711006-5003	JTC11016	<div data-bbox="858 344 983 472"> </div> <div data-bbox="1059 338 1219 403"> <p>OP10090 (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1059 461 1219 526"> <p>OP10092 (SEE APPLICATION CATALOGUE BY MODEL)</p> </div> <div data-bbox="1329 344 1453 584"> </div>
711006-5004	JTC11016	<div data-bbox="858 618 983 745"> </div>
711009-5001	JTC11016	<div data-bbox="858 768 983 896"> </div>
711009-5002	JTC11016	<div data-bbox="858 918 983 1046"> </div> <div data-bbox="1059 911 1136 938"> <p>OP10092</p> </div> <div data-bbox="1329 918 1453 1046"> </div>
711009-5003	JTC11016	<div data-bbox="858 1068 983 1196"> </div>
711017-5001	JTC11016	<div data-bbox="858 1218 983 1346"> </div>
711017-5002	JTC11016	<div data-bbox="858 1370 983 1498"> </div>
711017-5003	JTC11016	<div data-bbox="858 1518 983 1646"> </div> <div data-bbox="1059 1516 1136 1543"> <p>OP10093</p> </div> <div data-bbox="1329 1518 1453 1646"> </div>
711017-5004	JTC11016	<div data-bbox="858 1668 983 1796"> </div>
711736-5001	JTC11358	<div data-bbox="858 1821 983 1948"> </div>

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

711736-5023	JTC11565			
711736-5024	JTC11565			
711736-5026	JTC11565			
712077-5001	JTC11055			
712290-5001	JTC11145			
712541-5001	JTC11026			
712541-5002	JTC11026		OP10097	
712541-5003	JTC11026			
712541-5004	JTC11026			
712541-5005	JTC11026			
712541-5006	JTC11026			

		
712541-5007	JTC11026	
712766-5001	JTC11210	
712766-5002	JTC11210	
712968-5001	JTC11020	
712968-5002	JTC11020	
712968-5003	JTC11020	
712968-5004	JTC11020	
712968-5005	JTC11020	
712968-5006	JTC11020	 <p data-bbox="1059 1550 1219 1612">OP10001 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p data-bbox="1059 1673 1219 1736">OP10058 (SEE APPLICATION CATALOGUE BY MODEL)</p>  
712968-5007	JTC11020	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

			
713517-5005	JTC11239		
713517-5006	JTC11239		
713517-5007	JTC11239		
713517-5008	JTC11239		
713517-5009	JTC11239		
713517-5010	JTC11239		
713517-5011	JTC11239		
713517-5012	JTC11239		
713517-5015	JTC11239		
713517-5016	JTC11239		
713667-5001	JTC11348		

			<p>713667-5003</p>	<p>JTC11348</p>		
<p>713672-5002</p>	<p>JTC11020</p>		<p>OP10010 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10053 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10057 (SEE APPLICATION CATALOGUE BY MODEL)</p>			
<p>713672-5003</p>	<p>JTC11020</p>		<p>OP10010 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10053 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10057 (SEE APPLICATION CATALOGUE BY MODEL)</p>			
<p>713672-5004</p>	<p>JTC11020</p>		<p>OP10010 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10052 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10053 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10057 (SEE APPLICATION CATALOGUE BY MODEL)</p>			



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
All kits include the necessary components for one turbocharger.  
Scan QR code for a real picture of the product and technical tips.



713672-5005	JTC11020		<p><b>OP10010</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10053</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10057</b> (SEE APPLICATION CATALOGUE BY MODEL)</p>	
713672-5006	JTC11020		<p><b>OP10010</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10053</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10057</b> (SEE APPLICATION CATALOGUE BY MODEL)</p>	
713672-5007	JTC11020			
713673-5002	JTC11020		<p><b>OP10010</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10051</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10053</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10057</b> (SEE APPLICATION CATALOGUE BY MODEL)</p>	
713673-5003	JTC11020			
713673-5004	JTC11020			

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.



713673-5005	JTC11020	<p>OP10010 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10051 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10053 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10057 (SEE APPLICATION CATALOGUE BY MODEL)</p>
713673-5006	JTC11020	<p>OP10010 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10051 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10053 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10057 (SEE APPLICATION CATALOGUE BY MODEL)</p>
713673-5007	JTC11020	
714306-5005	JTC11380	
714306-5006	JTC11380	
714334-5001	JTC11361	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
714334-5002	JTC11361			
714467-5003	JTC11387			
714467-5004	JTC11387			
714467-5005	JTC11387			
714467-5007	JTC11387			
714467-5008	JTC11387			
714467-5010	JTC11387			
714467-5012	JTC11387			
714467-5013	JTC11387			
714467-5014	JTC11387			
714467-5015	JTC11387			

		
714485-5001	JTC11042	
714485-5002	JTC11042	
714485-5005	JTC11042	
714485-5006	JTC11042	
714485-5008	JTC11042	
714486-5001	JTC11042	
714486-5002	JTC11042	
714486-5005	JTC11042	
714486-5006	JTC11042	
714486-5008	JTC11042	
714568-5001	JTC11236	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
714568-5002	JTC11236			
714568-5003	JTC11236			
714619-5002	JTC11020			
714652-5004	JTC11238			
714652-5005	JTC11238			
714652-5006	JTC11238			
714716-5003	JTC11023			
714987-5001	JTC11211			
714987-5002	JTC11211			
714987-5003	JTC11211			
714987-5004	JTC11211			



		
714987-5005	JTC11211	
714987-5006	JTC11211	
715224-5001	JTC11420	
715224-5002	JTC11420	
715224-5003	JTC11420	
715294-5001	JTC11420	
715294-5002	JTC11420	
715294-5003	JTC11420	
715568-5001	JTC11428	
715568-5002	JTC11428	
715645-5004	JTC11566	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.



715735-5013	JTC11460			
715735-5014	JTC11460			
715735-5015	JTC11460			
715735-5016	JTC11460			
715735-5017	JTC11460			
715843-5001	JTC11196			
715910-5001	JTC11016		OP10092	
715910-5002	JTC11016		OP10092	
715910-5003	JTC11016			
715924-5001	JTC11196			
715924-5002	JTC11196			

		
715924-5003	JTC11196	
715924-5004	JTC11196	
716111-5001	JTC11197	
716213-5001	JTC11020	OP10057 
716215-5001	JTC11055	
716419-5001	JTC11020	
716541-5002	JTC11026	
716665-5001	JTC11357	
716665-5002	JTC11357	
716703-5001	JTC11007	
716860-5001	JTC11020	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.



				
716860-5002	JTC11020		<p>OP10051 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10057 (SEE APPLICATION CATALOGUE BY MODEL)</p>	 
716860-5003	JTC11020		<p>OP10051 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10057 (SEE APPLICATION CATALOGUE BY MODEL)</p>	 
716860-5004	JTC11020		<p>OP10051 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10057 (SEE APPLICATION CATALOGUE BY MODEL)</p>	 
716860-5005	JTC11020			
716885-5001	JTC11426			
716885-5002	JTC11426			
716885-5003	JTC11426			
716885-5004	JTC11426			
716885-5005	JTC11426			

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

		
717123-5001	JTC11007	
717345-5002	JTC11030	 <p>OP10031 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10095 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10096 (SEE APPLICATION CATALOGUE BY MODEL)</p> 
717348-5001	JTC11030	
717348-5002	JTC11030	
717384-5001	JTC11458	
717410-5007	JTC11350	
717478-5001	JTC11026	
717478-5002	JTC11026	
717478-5003	JTC11026	
717478-5004	JTC11026	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

717478-5005	JTC11026			
717478-5006	JTC11026			
717625-5001	JTC11280		<p>OP10006 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10072 (SEE APPLICATION CATALOGUE BY MODEL)</p>	
717626-5001	JTC11280			
717627-5002	JTC11280		<p>OP10006 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10020 (SEE APPLICATION CATALOGUE BY MODEL)</p>	
717628-5001	JTC11280			
717662-5001	JTC11419			
717662-5002	JTC11419			
717858-5001	JTC11055		<p>OP10060 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10082 (SEE APPLICATION CATALOGUE BY MODEL)</p>	

		
717858-5002	JTC11055	
717858-5003	JTC11055	 <p>OP10060 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10082 (SEE APPLICATION CATALOGUE BY MODEL)</p> 
717858-5004	JTC11055	
717858-5005	JTC11055	
717858-5006	JTC11055	
717858-5007	JTC11055	 <p>OP10060 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10082 (SEE APPLICATION CATALOGUE BY MODEL)</p> 
717858-5008	JTC11055	 <p>OP10060 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10082 (SEE APPLICATION CATALOGUE BY MODEL)</p> 
717858-5009	JTC11055	 <p>OP10060 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10082 (SEE APPLICATION CATALOGUE BY MODEL)</p> 



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

717858-5010	JTC11055			
718089-5001	JTC11237			
718089-5002	JTC11237			
718089-5003	JTC11237			
718089-5004	JTC11237			
718089-5005	JTC11237		OP10026	
718089-5006	JTC11237		OP10026	
718089-5007	JTC11237			
718089-5008	JTC11237		OP10026	
720168-5011	JTC11355			
720244-5001	JTC11238			

720244-5002	JTC11238			
720244-5003	JTC11238			
720244-5004	JTC11238			
720477-5001	JTC11025			
720855-5001	JTC11020		<p>OP10052 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10053 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10057 (SEE APPLICATION CATALOGUE BY MODEL)</p>	
720855-5003	JTC11020			
720855-5004	JTC11020			
720855-5005	JTC11020		<p>OP10052 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10053 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10057 (SEE APPLICATION CATALOGUE BY MODEL)</p>	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

720855-5006	JTC11020		<p>OP10052 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10053 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10057 (SEE APPLICATION CATALOGUE BY MODEL)</p>	
720855-5007	JTC11020			
720931-5001	JTC11426			
720931-5002	JTC11426			
720931-5003	JTC11426			
720931-5004	JTC11426			
720931-5005	JTC11426			
721021-5001	JTC11020			



		
721021-5004	JTC11020	 <p>OP10052 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10053 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10057 (SEE APPLICATION CATALOGUE BY MODEL)</p> 
721021-5005	JTC11020	 <p>OP10052 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10053 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10057 (SEE APPLICATION CATALOGUE BY MODEL)</p> 
721021-5006	JTC11020	 <p>OP10052 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10053 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10057 (SEE APPLICATION CATALOGUE BY MODEL)</p> 
721021-5008	JTC11020	
721164-5003	JTC11435	
721164-5004	JTC11435	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
All kits include the necessary components for one turbocharger.  
Scan QR code for a real picture of the product and technical tips.

721164-5011	JTC11435			
721164-5012	JTC11435			
721164-5013	JTC11435			
721164-5014	JTC11435			
721204-5001	JTC11390			
721875-5001	JTC11368			
721875-5005	JTC11368			
722010-5003	JTC11026		<p>OP10038 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10039 (SEE APPLICATION CATALOGUE BY MODEL)</p>	
722010-5004	JTC11026			
722010-5008	JTC11026			



		
722010-5010	JTC11026	
722011-5003	JTC11026	
722011-5004	JTC11026	
722011-5007	JTC11026	 <p data-bbox="1059 790 1219 853">OP10038 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p data-bbox="1059 913 1219 976">OP10039 (SEE APPLICATION CATALOGUE BY MODEL)</p>  
722011-5009	JTC11026	
722687-5001	JTC11352	
722730-5001	JTC11020	 <p data-bbox="1059 1366 1134 1391">OP10057</p> 
722730-5003	JTC11020	 <p data-bbox="1059 1516 1134 1541">OP10057</p> 
722730-5005	JTC11020	
722979-5003	JTC11364	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
723167-5001	JTC11353			
723167-5002	JTC11353			
723167-5003	JTC11353			
723167-5004	JTC11353			
723167-5007	JTC11644			
723212-5001	JTC11485			
723212-5003	JTC11485			
723213-5001	JTC11485			
723213-5003	JTC11485			
724483-5008	JTC11586			
724483-5009	JTC11586			

		
724495-5002	JTC11434	
724495-5003	JTC11434	
724495-5004	JTC11434	
724496-5004	JTC11458	
724639-5002	JTC11422	
724639-5004	JTC11422	
724639-5006	JTC11422	
724639-5007	JTC11422	
724808-5001	JTC11045	
724930-5002	JTC11330	
724930-5003	JTC11330	OP10052 



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
724930-5004	JTC11330		OP10052	
724930-5006	JTC11330			
724930-5008	JTC11330		OP10052	
724930-5009	JTC11330		OP10052	
724930-5010	JTC11330			
724961-5001	JTC11045			
724961-5002	JTC11045			
724961-5003	JTC11045			
724961-5004	JTC11045			
725071-5002	JTC11246			
725364-5006	JTC11026			



		
725364-5007	JTC11026	
725364-5012	JTC11026	
725364-5018	JTC11026	
725364-5021	JTC11026	OP10037 
725364-5022	JTC11026	
725864-5001	JTC11354	
725864-5002	JTC11354	
726194-5001	JTC11046	
726194-5002	JTC11046	
726194-5004	JTC11046	
726194-5005	JTC11023	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

726372-5005	JTC11486			
726372-5010	JTC11486			
726372-5013	JTC11486			
726683-5001	JTC11243			
726683-5002	JTC11243			
726683-5003	JTC11243			
726698-5001	JTC11016			
726698-5002	JTC11016			
726698-5003	JTC11016		<p><b>OP10017</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10090</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10092</b> (SEE APPLICATION CATALOGUE BY MODEL)</p>	
727210-5001	JTC11435			



		
727210-5003	JTC11435	OP10128
727211-5001	JTC11425	
727238-5001	JTC11425	
727262-5001	JTC11358	
727262-5002	JTC11358	
727262-5005	JTC11358	
727262-5006	JTC11358	
727264-5001	JTC11358	
727264-5003	JTC11358	
727264-5004	JTC11358	
727264-5005	JTC11358	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
727264-5007	JTC11358			
727265-5002	JTC11358			
727266-5001	JTC11358			
727266-5002	JTC11358			
727266-5003	JTC11358			
727271-5010	JTC11633			
727271-5011	JTC11633			
727461-5002	JTC11016			
727461-5003	JTC11016			
727461-5004	JTC11016			
727461-5005	JTC11016			

					
727461-5006	JTC11016				
727461-5007	JTC11016				
727463-5001	JTC11324				
727463-5002	JTC11324				
727463-5003	JTC11324				
727463-5004	JTC11324				
727477-5002	JTC11354				
727477-5005	JTC11354				
727477-5006	JTC11354				
727477-5007	JTC11354				
727477-5008	JTC11354				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
727730-5003	JTC11020			
728680-5007	JTC11046			
728680-5009	JTC11046			
728680-5010	JTC11046			
728680-5012	JTC11046			
728680-5013	JTC11023			
728680-5015	JTC11046			
728680-5020	JTC11046			
728989-5003	JTC11026			
728989-5007	JTC11026			
728989-5010	JTC11026			

		
728989-5015	JTC11026	
728989-5016	JTC11026	
728989-5018	JTC11026	OP10040 
728989-5019	JTC11026	
729041-5009	JTC11459	
729125-5007	JTC11596	
729125-5013	JTC11596	
729325-5002	JTC11488	
729325-5003	JTC11488	
729325-5004	JTC11488	
729546-5001	JTC11369	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

731320-5001	JTC11360			
731877-5001	JTC11026			
731877-5003	JTC11026			
731877-5004	JTC11026			
731877-5006	JTC11026			
731877-5007	JTC11026			
731877-5009	JTC11026		OP10034	
731877-5010	JTC11026			
733701-5001	JTC11026			
733717-5001	JTC11045			
733783-5004	JTC11534			



		
733783-5007	JTC11534	
733783-5008	JTC11534	
733952-5001	JTC11421	
733952-5004	JTC11421	
734204-5001	JTC11359	
734899-5001	JTC11016	
734899-5002	JTC11016	
735059-5001	JTC11208	
735059-5002	JTC11208	
735059-5003	JTC11208	
735059-5004	JTC11208	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

735059-5005	JTC11208			
735059-5006	JTC11208			
736088-5003	JTC11016			
736168-5003	JTC11210			
738123-5001	JTC11030		OP10015	
738123-5002	JTC11030			
738123-5003	JTC11030			
738123-5004	JTC11030			
738123-5005	JTC11030			
739542-5001	JTC11158			
739542-5002	JTC11158			

		
739542-5005	JTC11158	
739542-5006	JTC11158	
739548-5001	JTC11047	
739548-5005	JTC11340	
740611-5001	JTC11544	
740611-5002	JTC11544	
740611-5003	JTC11544	
740611-5005	JTC11544	
740911-5001	JTC11026	
740911-5003	JTC11026	
740911-5006	JTC11026	OP10034 



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
740911-5007	JTC11026			
741785-5010	JTC11026			
741785-5013	JTC11026			
741785-5014	JTC11026		OP10041	
741785-5016	JTC11026			
742110-5004	JTC11476			
742110-5006	JTC11476			
742110-5007	JTC11476			
742289-5001	JTC11484			
742289-5002	JTC11484			
742289-5003	JTC11484			

				
742289-5004	JTC11484			
742289-5005	JTC11484			
742614-5002	JTC11020			
742614-5003	JTC11020		OP10057	
742614-5004	JTC11020			
742693-5001	JTC11016			
742693-5002	JTC11016			
742693-5003	JTC11016		OP10017	
742693-5004	JTC11016			
742730-5001	JTC11026			
742730-5003	JTC11026			



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

742730-5004	JTC11026			
742730-5007	JTC11026			
742730-5013	JTC11026			
742730-5015	JTC11026			
742730-5018	JTC11026		OP10037	
742730-5019	JTC11026			
742809-5003	JTC11485			
742809-5005	JTC11485			
742809-5007	JTC11485			
742810-5003	JTC11485			
742810-5005	JTC11485			

				
742810-5007	JTC11485			
743115-5001	JTC11016		OP10027	
743115-5003	JTC11016			
743317-5001	JTC11425			
743347-5002	JTC11340			
743347-5004	JTC11340			
743436-5001	JTC11016		OP10027	
743436-5003	JTC11016			
750030-5002	JTC11351		<p>OP10013 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10023 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10107 (SEE APPLICATION CATALOGUE BY MODEL)</p>	  
750080-5001	JTC11026			

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

750080-5007	JTC11026			
750080-5013	JTC11026			
750080-5015	JTC11026			
750080-5016	JTC11026			
750080-5018	JTC11026		OP10037	
750080-5019	JTC11026			
750431-5004	JTC11026			
750431-5007	JTC11026			
750431-5009	JTC11026		OP10034	
750431-5010	JTC11026			
750431-5012	JTC11026			

		
750431-5013	JTC11026	
750441-5005	JTC11473	
750510-5001	JTC11461	
750639-5002	JTC11419	
750720-5001	JTC11424	
750720-5002	JTC11424	
750720-5003	JTC11424	
750773-5001	JTC11026	
750773-5004	JTC11026	
750773-5007	JTC11026	
750773-5013	JTC11026	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

750773-5015	JTC11026			
750773-5017	JTC11026			
750849-5001	JTC11503			
750952-5001	JTC11026			
750952-5004	JTC11026			
750952-5007	JTC11026			
750952-5010	JTC11026			
750952-5013	JTC11026			
750952-5014	JTC11026		OP10041	
750952-5017	JTC11026			
751243-5002	JTC11483			



751418-5002	JTC11464			
751578-5001	JTC11346			
751578-5002	JTC11346			
751758-5001	JTC11361			
751758-5002	JTC11361			
751768-5001	JTC11030			
751768-5002	JTC11030			
751768-5003	JTC11030		<p>OP10031 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10095 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10096 (SEE APPLICATION CATALOGUE BY MODEL)</p>	
751768-5004	JTC11030			
751768-5005	JTC11030			

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

751851-5001	JTC11378			
751851-5002	JTC11378			
751851-5003	JTC11378		<p>OP10052 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10062 (SEE APPLICATION CATALOGUE BY MODEL)</p>	
751851-5004	JTC11378			
752233-5002	JTC11387			
752233-5003	JTC11387			
752233-5007	JTC11387			
752233-5008	JTC11387			
752233-5009	JTC11387			
752341-5003	JTC11567			



				
752341-5006	JTC11567			
752343-5003	JTC11567			
752343-5006	JTC11567			
752610-5009	JTC11504		OP10131	
752610-5010	JTC11504		OP10131	
752610-5012	JTC11504		OP10131	
752610-5013	JTC11504		OP10131	
752610-5015	JTC11504		OP10131	
752610-5025	JTC11504		OP10131	
752610-5026	JTC11504		OP10131	
752610-5029	JTC11504		OP10131	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
752610-5032	JTC11504		OP10131	
752990-5006	JTC11568			
752990-5007	JTC11568			
753392-5001	JTC11026			
753392-5003	JTC11026			
753392-5015	JTC11026			
753392-5016	JTC11026			
753392-5017	JTC11026			
753392-5018	JTC11026			
753392-5019	JTC11026			



<p>753420-5002</p>	<p>JTC11351</p> 	<p>OP10012 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10013 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10023 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10042 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10049 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10107 (SEE APPLICATION CATALOGUE BY MODEL)</p> 
<p>753420-5003</p>	<p>JTC11351</p> 	
<p>753420-5004</p>	<p>JTC11351</p> 	
<p>753420-5005</p>	<p>JTC11351</p> 	<p>OP10012 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10013 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10042 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10049 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10050 (SEE APPLICATION CATALOGUE BY MODEL)</p> 



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

			
753420-5006	JTC11351		
753481-5001	JTC11609		
753481-5002	JTC11609		
753481-5004	JTC11609		
753481-5010	JTC11609		
753519-5007	JTC11505		OP10130
753519-5009	JTC11505		OP10130
753544-5017	JTC11618		
753544-5020	JTC11618		
753546-5014	JTC11612		
753546-5023	JTC11612		



		
753583-5004	JTC11785	
753708-5005	JTC11596	
753959-5005	JTC11461	
754821-5001	JTC11436	 <p data-bbox="1059 792 1219 855">OP10112 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p data-bbox="1059 916 1219 978">OP10132 (SEE APPLICATION CATALOGUE BY MODEL)</p>  
755173-5003	JTC11617	
755173-5004	JTC11617	
755173-5005	JTC11617	
755173-5006	JTC11617	
755173-5009	JTC11617	
755297-5001	JTC11613	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
755297-5003	JTC11613			
755297-5004	JTC11613			
755297-5005	JTC11613			
755298-5001	JTC11613			
755298-5003	JTC11613			
755298-5004	JTC11613			
755298-5005	JTC11613			
755299-5001	JTC11485			
755299-5003	JTC11485			
755299-5005	JTC11485			
755299-5006	JTC11485			



					
755299-5007	JTC11485				
755300-5001	JTC11485				
755300-5003	JTC11485				
755300-5005	JTC11485				
755300-5006	JTC11485				
755300-5007	JTC11485				
755310-5001	JTC11604				
755448-5005	JTC11620				
755507-5001	JTC11462				
755507-5002	JTC11462				
755507-5003	JTC11462				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
755507-5006	JTC11462			
755507-5007	JTC11462			
755507-5008	JTC11462			
755507-5009	JTC11462			
755507-5011	JTC11462			
755862-5003	JTC11617			
755862-5004	JTC11617			
755862-5005	JTC11617			
755862-5006	JTC11617			
755925-5001	JTC11464			
756047-5002	JTC11432			



				
756047-5004	JTC11432			
756047-5005	JTC11432		OP10049	
756047-5006	JTC11432			
756062-5001	JTC11330			
756062-5002	JTC11330			
756062-5003	JTC11330			
756062-5004	JTC11330			
756068-5001	JTC11362			
756867-5001	JTC11482			
756867-5002	JTC11482			
756867-5003	JTC11482			



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
756919-5002	JTC11023			
757042-5008	JTC11330			
757042-5008	JTC11704			
757042-5010	JTC11330			
757042-5010	JTC11704			
757042-5011	JTC11330			
757042-5011	JTC11704			
757042-5013	JTC11330			
757042-5013	JTC11704			
757042-5014	JTC11330			
757042-5014	JTC11704			



		
757042-5015	JTC11330	 <p>OP10001 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10052 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10062 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10063 (SEE APPLICATION CATALOGUE BY MODEL)</p> 
757042-5015	JTC11704	 <p>OP10001 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10052 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10062 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10063 (SEE APPLICATION CATALOGUE BY MODEL)</p> 
757042-5016	JTC11330	
757042-5016	JTC11704	
757246-5001	JTC11475	
757349-5001	JTC11506	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
757349-5002	JTC11506			
757349-5003	JTC11506			
757349-5004	JTC11506			
757779-5004	JTC11582			
757779-5010	JTC11582			
757779-5020	JTC11582			
757779-5021	JTC11582			
757779-5022	JTC11582			
757886-5003	JTC11474			
757886-5004	JTC11474			
757886-5005	JTC11474			

		
757886-5006	JTC11474	
757886-5007	JTC11474	
757886-5008	JTC11474	 <p data-bbox="1059 640 1219 703">OP10118 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p data-bbox="1059 763 1219 826">OP10119 (SEE APPLICATION CATALOGUE BY MODEL)</p> 
758219-5002	JTC11008	
758219-5003	JTC11008	 <p data-bbox="1059 1066 1136 1088">OP10060</p> 
758219-5004	JTC11008	
758226-5004	JTC11387	
758226-5008	JTC11387	
758226-5010	JTC11387	
758226-5014	JTC11387	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
758351-5005	JTC11463			
758351-5022	JTC11463			
758352-5022	JTC11463			
758352-5024	JTC11463			
758352-5026	JTC11463		OP10035	
758353-5022	JTC11463			
758353-5024	JTC11463		OP10035	
758532-5019	JTC11476			
758870-5001	JTC11464			
759394-5002	JTC11616			
759688-5002	JTC11016			

		
759688-5003	JTC11016	
759688-5005	JTC11016	
759688-5007	JTC11016	OP10017 
759688-5009	JTC11016	
760220-5003	JTC11432	OP10001 
760220-5004	JTC11432	
760497-5002	JTC11357	
760680-5002	JTC11536	
760680-5003	JTC11536	
760680-5004	JTC11536	
760680-5005	JTC11536	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

760680-5006	JTC11536			
760698-5002	JTC11552			
760698-5003	JTC11552			
760698-5004	JTC11552			
760698-5005	JTC11552			
760699-5004	JTC11552			
760700-5004	JTC11552			
760774-5003	JTC11432		OP10009	
760774-5005	JTC11432			
760822-5001	JTC11436		OP10112 <small>(SEE APPLICATION CATALOGUE BY MODEL)</small>  OP10132 <small>(SEE APPLICATION CATALOGUE BY MODEL)</small>	



		
761437-5005	JTC11055	
761618-5001	JTC11462	
761618-5002	JTC11462	
761618-5003	JTC11462	
761618-5004	JTC11462	
761650-5001	JTC11596	
761650-5002	JTC11596	
762060-5006	JTC11741	
762060-5008	JTC11741	
762060-5009	JTC11741	
762084-5002	JTC11461	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

762328-5001	JTC11351		OP10049 (SEE APPLICATION CATALOGUE BY MODEL)  OP10050 (SEE APPLICATION CATALOGUE BY MODEL)	
762328-5002	JTC11351		OP10049 (SEE APPLICATION CATALOGUE BY MODEL)  OP10050 (SEE APPLICATION CATALOGUE BY MODEL)	
762328-5003	JTC11351			
762463-5002	JTC11590			
762463-5003	JTC11590			
762463-5004	JTC11590			
762463-5006	JTC11590			
762660-5002	JTC11584			
762785-5001	JTC11507			
762785-5002	JTC11507			



		
762785-5003	JTC11507	
762785-5004	JTC11507	
762965-5001	JTC11026	
762965-5002	JTC11026	
762965-5003	JTC11026	
762965-5007	JTC11026	
762965-5008	JTC11026	
762965-5009	JTC11026	
762965-5017	JTC11026	OP10034 
762965-5020	JTC11026	
763360-5001	JTC11475	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
763492-5005	JTC11614			
763493-5005	JTC11614			
763647-5014	JTC11476			
763647-5019	JTC11476			
763647-5021	JTC11476			
763980-5004	JTC11569			
763980-5005	JTC11569			
763980-5007	JTC11569			
764509-5001	JTC11432			
764609-5001	JTC11432			
764609-5003	JTC11432			

		
764809-5001	JTC11478	
764809-5002	JTC11478	
764809-5004	JTC11478	
765015-5001	JTC11477	
765015-5002	JTC11477	
765015-5003	JTC11477	
765015-5004	JTC11477	
765015-5005	JTC11477	
765015-5006	JTC11477	
765016-5001	JTC11583	
765016-5002	JTC11583	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
765016-5003	JTC11583			
765016-5004	JTC11583			
765016-5005	JTC11583			
765016-5006	JTC11583			
765017-5001	JTC11592			
765017-5002	JTC11592			
765017-5003	JTC11592			
765017-5004	JTC11592			
765017-5006	JTC11592			
765155-5004	JTC11478			
765155-5007	JTC11478			

				
765155-5008	JTC11478			
765156-5003	JTC11478			
765156-5004	JTC11478			
765156-5007	JTC11478			
765156-5008	JTC11478			
765261-5002	JTC11482		OP10063	
765261-5003	JTC11482		OP10063	
765261-5004	JTC11482		OP10063	
765261-5005	JTC11482		OP10063	
765261-5006	JTC11482		OP10063	
765261-5007	JTC11482		OP10063	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

765261-5008	JTC11482		OP10063	
765277-5001	JTC11419			
765312-5002	JTC11614			
765313-5002	JTC11614			
765472-5001	JTC11360			
765985-5006	JTC11463			
765985-5008	JTC11463			
765985-5010	JTC11463		OP10035	
765993-5004	JTC11432		OP10014	
766111-5001	JTC11599			
766259-5001	JTC11464			

766340-5001	JTC11489	OP10105 (SEE APPLICATION CATALOGUE BY MODEL)  OP10111 (SEE APPLICATION CATALOGUE BY MODEL)
766891-5001	JTC11753	
767378-5005	JTC11570	OP10121
767378-5006	JTC11570	OP10121
767378-5007	JTC11570	OP10121
767378-5008	JTC11570	OP10121
767378-5009	JTC11570	OP10121
767378-5010	JTC11570	OP10121
767378-5013	JTC11570	OP10121
767378-5014	JTC11570	OP10121

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.



767835-5001	JTC11436		<p><b>OP10106</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10112</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10115</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10132</b> (SEE APPLICATION CATALOGUE BY MODEL)</p>	
767835-5003	JTC11436		<p><b>OP10106</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10112</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10115</b> (SEE APPLICATION CATALOGUE BY MODEL)</p>	
767837-5001	JTC11436		<p><b>OP10112</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10132</b> (SEE APPLICATION CATALOGUE BY MODEL)</p>	
767837-5002	JTC11436		<p><b>OP10112</b></p>	
767851-5001	JTC11530			
767851-5003	JTC11530			

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.



767878-5001	JTC11571	
767933-5015	JTC11505	
768239-5001	JTC11020	
768329-5001	JTC11020	<p>OP10010 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10053 (SEE APPLICATION CATALOGUE BY MODEL)</p>
768329-5003	JTC11020	
768625-5002	JTC11461	
768652-5001	JTC11330	
768652-5001	JTC11704	
768652-5003	JTC11330	
768652-5003	JTC11704	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

768652-5004	JTC11330			
768737-5001	JTC11436			
769040-5001	JTC11572			
769328-5001	JTC11624			
769393-5001	JTC11723			
769701-5001	JTC11487			
769701-5002	JTC11487			
769701-5003	JTC11487			
769705-5008	JTC11510			
769708-5001	JTC11508			
769708-5002	JTC11508			



					
769708-5003	JTC11508				
769708-5004	JTC11508				
769901-5001	JTC11723				
769901-5002	JTC11723				
769901-5003	JTC11723				
770116-5001	JTC11509				
770116-5002	JTC11509				
770895-5002	JTC11591				
770895-5007	JTC11591				
770895-5008	JTC11591				
771847-5001	JTC11343				

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
771953-5001	JTC11628			
771954-5001	JTC11628			
771955-5001	JTC11628			
773087-5001	JTC11509			
773087-5002	JTC11509			
773087-5003	JTC11509			
773098-5002	JTC11633			
773098-5005	JTC11633			
773098-5006	JTC11633			
773098-5008	JTC11633			
773148-5001	JTC11584			



773720-5001	JTC11489	<p>OP10111 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10133 (SEE APPLICATION CATALOGUE BY MODEL)</p>
773721-5001	JTC11489	<p>OP10111 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10133 (SEE APPLICATION CATALOGUE BY MODEL)</p>
774193-5003	JTC11739	
774833-5001	JTC11592	
774833-5002	JTC11592	
775274-5002	JTC11599	
775517-5001	JTC11620	
775517-5002	JTC11620	
776469-5004	JTC11510	
776469-5005	JTC11510	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
776470-5001	JTC11621			
776470-5003	JTC11621			
777159-5003	JTC11510			
777250-5001	JTC11357			
777251-5001	JTC11210			
777318-5001	JTC11478			
777853-5013	JTC11630			
777948-5003	JTC11627			
778088-5001	JTC11723			
778400-5001	JTC11779			
778400-5003	JTC11779			



778400-5004	JTC11779			
778401-5004	JTC11779			
778401-5005	JTC11779			
778401-5006	JTC11779			
778401-5007	JTC11779			
778401-5008	JTC11779			
778794-5001	JTC11016		<p>OP10017 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10090 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10092 (SEE APPLICATION CATALOGUE BY MODEL)</p>	
779591-5001	JTC11607			
779591-5002	JTC11607			
779591-5004	JTC11607			



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
780502-5001	JTC11619			
780708-5002	JTC11626			
780708-5003	JTC11626			
780708-5005	JTC11626			
781504-5001	JTC11625			
781504-5002	JTC11625			
781504-5004	JTC11625			
781743-5001	JTC11478			
781743-5003	JTC11591			
782053-5001	JTC11432			
782097-5001	JTC11736			

					
782217-5001	JTC11764				
782217-5002	JTC11764				
782403-5001	JTC11544				
783248-5003	JTC11634				
783762-5002	JTC11621				
783887-5001	JTC11490				
784011-5005	JTC11635				
784114-5002	JTC11619				
784844-5001	JTC11753				
785437-5001	JTC11622				
785437-5002	JTC11622				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
785448-5005	JTC11620			
786137-5001	JTC11753			
786137-5003	JTC11753			
786997-5001	JTC11606			
787274-5001	JTC11753			
787556-5016	JTC11786			
787556-5017	JTC11786			
787630-5001	JTC11744			
788290-5001	JTC11753			
789016-5001	JTC11605			
789016-5002	JTC11605			



		
792290-5002	JTC11620	
792290-5003	JTC11620	
799171-5001	JTC11722	
801891-5001	JTC11435	OP10128 
801891-5002	JTC11435	OP10128  
801891-5003	JTC11435	OP10128  
801891-5004	JTC11435	OP10128  
802012-5001	JTC11586	
802013-5001	JTC11596	
802014-5001	JTC11596	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

802418-5001	JTC11239		OP10007 (SEE APPLICATION CATALOGUE BY MODEL)  OP10008 (SEE APPLICATION CATALOGUE BY MODEL)	
802419-5001	JTC11023			
802419-5002	JTC11023			
802419-5003	JTC11023			
802419-5004	JTC11023			
802419-5005	JTC11023			
802419-5006	JTC11023			
802419-5008	JTC11023			
802419-5009	JTC11023			
802419-5010	JTC11023			

					
802774-5004	JTC11791				
802774-5005	JTC11791				
804963-5001	JTC11774				
804968-5001	JTC11778				
804968-5002	JTC11778				
804968-5003	JTC11778				
804968-5004	JTC11778				
806291-5001	JTC11635				
806291-5002	JTC11635				
806497-5001	JTC11634				
806498-5001	JTC11785				

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.





807068-5001

JTC11753





*HITACHI*



			
HT10-9	JTC11439		
HT10-18	JTC11414		
HT12	JTC11550		
HT12-19D	JTC11632		
HT12-22D	JTC11550		
HT15-48B	JTC11733		
KT10 1B	JTC11535		



*HOLSET*

2593593	JTC11444			
3501126	JTC11057			
3501756	JTC11269			
3503044	JTC11155			
3504484	JTC11392			
3518613	JTC11151			
3518791	JTC11057			
3518792	JTC11057			
3518895	JTC11057			
3518911	JTC11054			
3519143	JTC11057			

					
3519605	JTC11057				
3521362	JTC11152				
3521945	JTC11172				
3521971	JTC11288				
3522346	JTC11153				
3522572	JTC11057				
3522778	JTC11154				
3522900	JTC11139				
3523022	JTC11151				
3523055	JTC11392				
3523134	JTC11151				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

			
3523646	JTC11156		
3523649	JTC11409		
3524034	JTC11157		
3524689	JTC11406		
3525088	JTC11269		
3525150	JTC11269		
3525178	JTC11392		
3525237	JTC11158		
3525351	JTC11288		
3525447	JTC11289		
3525517	JTC11140		

					
3525633	JTC11159				
3525692	JTC11392				
3525994	JTC11151				
3526008	JTC11123				
3526025	JTC11265				
3526487	JTC11289				
3526646	JTC11301				
3526708	JTC11160				
3526955	JTC11160				
3526963	JTC11160				
3527107	JTC11157				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

3527396	JTC11338			
3527751	JTC11405			
3527997	JTC11151			
3528018	JTC11151			
3528087	JTC11289			
3528128	JTC11290			
3528352	JTC11406			
3528354	JTC11288			
3528568	JTC11406			
3528650	JTC11151			
3528651	JTC11151			



					
3528741	JTC11408				
3528752	JTC11157				
3528777	JTC11121				
3529154	JTC11406				
3530536	JTC11151				
3530555	JTC11123				
3530890	JTC11392				
3530980	JTC11252				
3531228	JTC11392				
3531669	JTC11392				
3531696	JTC11178				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

3531719	JTC11151			
3531896	JTC11406			
3533013	JTC11058			
3533915	JTC11407			
3533988	JTC11404			
3534355	JTC11151			
3534521	JTC11514			
3534960	JTC11168			
3535635	JTC11515			
3536359	JTC11491			
3536531	JTC11491			



		
3536545	JTC11245	
3536564	JTC11392	
3536675	JTC11466	
3536816	JTC11054	
3537132	JTC11408	
3537202	JTC11058	
3537568	JTC11058	
3537639	JTC11151	
3537762	JTC11058	
3537840	JTC11212	
3538119	JTC11058	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

			
3538350	JTC11058		
3538353	JTC11058		
3538497	JTC11609		
3538548	JTC11058		
3538716	JTC11433		
3538752	JTC11157		
3538772	JTC11410		
3538852	JTC11058		
3538856	JTC11058		
3539343	JTC11057		
3539369	JTC11057		



					
3539371	JTC11057				
3539502	JTC11057				
3539506	JTC11057				
3545575	JTC11057				
3545576	JTC11058				
3545577	JTC11392				
3545741	JTC11269				
3575216	JTC11157				
3575671	JTC11123				
3580177	JTC11010				
3580178	JTC11010				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
3580214	JTC11054			
3580266	JTC11039			
3580274	JTC11039			
3580526	JTC11433			
3580566	JTC11265			
3580790	JTC11209			
3590005	JTC11392			
3590273	JTC11433			
3590506	JTC11265			
3590810	JTC11157			
3591077	JTC11433			



					
3591167	JTC11284				
3591587	JTC11415				
3591768	JTC11054				
3591770	JTC11151				
3591781	JTC11157				
3591830	JTC11410				
3591880	JTC11375				
3591999	JTC11285				
3592003	JTC11400				
3592005	JTC11407				
3592007	JTC11407				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
3592015	JTC11178			
3592736	JTC11151			
3593373	JTC11057			
3593413	JTC11245			
3593593	JTC11444			
3593832	JTC11376			
3593894	JTC11051			
3593896	JTC11051			
3593918	JTC11407			
3594557	JTC11376			
3594875	JTC11376			

		
3594948	JTC11376	
3595118-D	JTC11245	
3595671	JTC11377	
3595780	JTC11491	
3595937	JTC11444	
3596124	JTC11279	
3596147	JTC11467	
3596457	JTC11392	
3596597	JTC11468	
3596647	JTC11469	
3597180	JTC11470	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
3597181	JTC11470			
3597276	JTC11376			
3597285	JTC11051			
3597501	JTC11407			
3597546	JTC11290			
3597659	JTC11284			
3597728	JTC11433			
3598517	JTC11376			
3598723	JTC11468			
3599049	JTC11468			
3599242	JTC11468			



		
3599350	JTC11468	
4027081	JTC11392	
4027206	JTC11123	
4027565	JTC11209	
4027573	JTC11404	
4027594	JTC11404	
4027596	JTC11404	
4027639	JTC11404	
4027672	JTC11054	
4027677	JTC11404	
4027733	JTC11404	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

4027762	JTC11010			
4027793	JTC11404			
4027901	JTC11054			
4031396	JTC11057			
4035100	JTC11058			
4035105	JTC11058			
4035107	JTC11058			
4035110	JTC11058			
4035316	JTC11057			
4035393	JTC11468			
4035961	JTC11057			



					
4036282	JTC11377				
4036531	JTC11471				
4037181	JTC11433				
4038389	JTC11376				
4038393	JTC11376				
4038396	JTC11376				
4038876	JTC11433				
4039264	JTC11057				
4039850	JTC11433				
4040718-D	JTC11245				
4041367	JTC11468				

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

			
4041615	JTC11609		
4042550	JTC11376		
4044198	JTC11433		
4044200	JTC11433		
4045477	JTC11433		
4046928	JTC11376		
4046945	JTC11377		
54334	JTC11170		
54376	JTC11176		





03F145701F	JTC11706			
03F145701L	JTC11706			
03F145701LV	JTC11706			
03F145701LX	JTC11706			
110921-0219	JTC11781			
110921-0252	JTC11781			
1720087703000	JTC11761			
CI39 / RHB7	JTC11050			
CY26 / RHB3	JTC11309			
CY62 / RHB3	JTC11309			
F400007	JTC11532			

		
MV1 / RHB5	JTC11272	
MY34 / RHB5	JTC11308	
MY60 / RHB5	JTC11308	
MY61 / RHB3	JTC11309	
MY65 / RHB3	JTC11308	
MY67 / RHB5	JTC11308	
NB130014	JTC11192	
NB130015	JTC11309	
NB130024	JTC11309	
NB130038	JTC11192	
NB150012	JTC11308	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

NB150025	JTC11396			
NB150026	JTC11394			
NB150028	JTC11397			
NB150040	JTC11297			
NB150042	JTC11396			
NB150045	JTC11308			
NB150046	JTC11297			
NB150060	JTC11396			
NB150061	JTC11396			
NB190016	JTC11393			
NE130060	JTC11395			

		
NN130046	JTC11395	
NN130060	JTC11395	
NN130066	JTC11272	
NN130067	JTC11394	
NN130068	JTC11394	
NN170025	JTC11050	
RHB4 / VI72	JTC11194	
RHB4-RHF4	JTC11194	
RHF4 / VF14	JTC11384	
RHF4 / VIBD	JTC11194	
RHF4H VL25	JTC11532	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

RHF4V / VJ32	JTC11382			
RHF5-VJ26	JTC11533			
RHF5-VJ33	JTC11533			
T3P9C / RHB4	JTC11194			
V30A0004	JTC11298			
VA110017	JTC11308			
VA110021	JTC11309			
VA110024	JTC11309			
VA110033	JTC11309			
VA120011	JTC11194			
VA120012	JTC11194			

		
VA120015	JTC11194	
VA130011	JTC11194	
VA130012	JTC11194	
VA130015	JTC11194	
VA130016	JTC11395	
VA130018	JTC11394	
VA130039	JTC11308	
VA130047	JTC11297	
VA130057	JTC11297	
VA130063	JTC11395	
VA130066	JTC11395	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

VA130067	JTC11395			
VA130068	JTC11398			
VA130071	JTC11297			
VA130077	JTC11277			
VA130085	JTC11308			
VA140015	JTC11393			
VA150022	JTC11050			
VA180014	JTC11391			
VA180027	JTC11297			
VA180029	JTC11277			
VA180030	JTC11277			

		
VA180033	JTC11297	
VA180047	JTC11193	
VA180051	JTC11297	
VA180053	JTC11223	
VA180055	JTC11223	
VA180056	JTC11223	
VA180062	JTC11275	
VA180069	JTC11223	
VA180071	JTC11223	
VA180074	JTC11295	
VA180086	JTC11223	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

VA180094	JTC11277			
VA180098	JTC11277			
VA190011	JTC11223			
VA190014	JTC11278			
VA410018	JTC11292			
VA410059	JTC11062			
VA420011	JTC11194			
VA420058	JTC11445			
VA420088	JTC11593			
VA430015	JTC11260			
VA430023	JTC11293			

		
VA430036	JTC11356	
VA430047	JTC11297	
VA430048	JTC11297	
VA430064	JTC11589	
VA430070	JTC11294	
VA430089	JTC11533	
VA430090	JTC11533	
VA55B / RHB5	JTC11223	
VA56A / RHB5	JTC11223	
VA58A / RHB5	JTC11223	
VA58B / RHB5	JTC11223	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

VA59A / RHB5	JTC11223			
VA59B / RHB5	JTC11223			
VA60A	JTC11275			
VA63A / RHB5	JTC11223			
VA63B	JTC11278			
VA63B / RHB5	JTC11278			
VA640031	JTC11729			
VA660011	JTC11297			
VA660015	JTC11297			
VA67	JTC11293			
VA69	JTC11293			

VA80	JTC11293				
VB10	JTC11718				
VB110021	JTC11309				
VB110033	JTC11309				
VB130022	JTC11397				
VB130023	JTC11396				
VB130024	JTC11396				
VB130033	JTC11397				
VB130068	JTC11398				
VB130076	JTC11277				
VB130077	JTC11277				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

VB14	JTC11543			
VB16	JTC11543			
VB180014	JTC11391			
VB180047	JTC11193			
VB180053	JTC11223			
VB180056	JTC11223			
VB180074	JTC11295			
VB190011	JTC11223			
VB190014	JTC11278			
VB21	JTC11543			
VB410018	JTC11292			

		
VB410047	JTC11498	
VB420011	JTC11194	
VB420051	JTC11445	
VB420058	JTC11445	
VB420088	JTC11593	
VB420119	JTC11623	
VB430015	JTC11260	
VB430023	JTC11293	
VB430036	JTC11356	
VB430089	JTC11533	
VB430090	JTC11533	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

VB640031	JTC11729			
VB730020	JTC11539			
VBA10018	JTC11499			
VC120012	JTC11194			
VC130016	JTC11395			
VC130057	JTC11297			
VC130067	JTC11395			
VC130071	JTC11297			
VC130076	JTC11277			
VC130077	JTC11277			
VC180029	JTC11277			

		
VC180030	JTC11277	
VC180047	JTC11193	
VC180051	JTC11297	
VC180056	JTC11223	
VC180071	JTC11223	
VC420088	JTC11593	
VC430011	JTC11446	
VC430015	JTC11260	
VC430089	JTC11533	
VC430090	JTC11533	
VCA10019	JTC11382	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

VD130047	JTC11297			
VD130067	JTC11395			
VD180027	JTC11297			
VD180051	JTC11297			
VD180071	JTC11223			
VD430023	JTC11293			
VD430090	JTC11533			
VD440022	JTC11296			
VD650012	JTC11384			
VDD20018	JTC11772			
VE120011	JTC11194			

		
VE120012	JTC11194	
VE130018	JTC11394	
VE130076	JTC11277	
VE130077	JTC11277	
VE180027	JTC11297	
VE430015	JTC11260	
VE430023	JTC11293	
VE430090	JTC11533	
VE660015	JTC11297	
VF130047	JTC11297	
VF130071	JTC11297	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

VF35	JTC11296			
VF40A132	JTC11016			
VF40A281	JTC11500			
VF420014	JTC11366			
VF430015	JTC11260			
VF50	JTC11772			
VF660015	JTC11297			
VG110045	JTC11167			
VG130018	JTC11394			
VG430015	JTC11260			
VH130071	JTC11297			

		
VH660011	JTC11297	
VHD20012	JTC11549	
VHD20021	JTC11501	
VI34 / RHB5	JTC11395	
VI58 / RHB5	JTC11297	
VI660011	JTC11297	
VI72 / RHB4	JTC11194	
VI74 / RHB5	JTC11297	
VI94 / RHB4	JTC11194	
VI95	JTC11297	
VI95 / RHB5	JTC11297	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

VIAH / RHB5	JTC11297			
VIAM / RHF5	JTC11297			
VIAW / RHF5	JTC11297			
VIBD / RHF4	JTC11194			
VIBG	JTC11292			
VIBG / RHF3	JTC11292			
VIBM - RHE7	JTC11539			
VIBR	JTC11366			
VICC	JTC11293			
VICC / RHF5	JTC11293			
VICF	JTC11260			

		
VIDF-RHF5	JTC11589	
VIDS	JTC11294	
VIFC	JTC11607	
VJ11 / RHB5	JTC11397	
VJ14 / RHB5	JTC11396	
VJ21 / RHB5	JTC11398	
VJ24 / RHF5	JTC11446	
VJ27 RHF3H	JTC11498	
VJ30 RHF4V	JTC11499	
VJ36	JTC11549	
VJ37	JTC11549	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

VJ38 RHV4	JTC11501		
VJ40	JTC11769		
VJ9 / RHB5	JTC11396		
VK430015	JTC11260		
VL1 / RHB5	JTC11395		
VL10	JTC11277		
VL11	JTC11277		
VL17	JTC11297		
VL18	JTC11297		
VL180102	JTC11297		
VL20	JTC11062		



		
VL3 / RHB5	JTC11395	
VL37	JTC11724	
VL430015	JTC11260	
VL5 / RHB5	JTC11391	
VL7	JTC11193	
VL7 / RHB5	JTC11193	
VL8	JTC11295	OP10102 
VM20 / RHB5	JTC11277	
VM20R / RHB5	JTC11277	
VM21L / RHB5	JTC11277	
VM22R / RHB5	JTC11277	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

VM23L / RHB5	JTC11277			
VM5L / RHB5	JTC11394			
VM6R / RHB5	JTC11394			
VN2	JTC11445			
VN3 / RHF4H	JTC11445			
VN4	JTC11623			
VQ10 / RHB5	JTC11394			
VQ12 / RHB3	JTC11192			
VQ15 / RHB5	JTC11297			
VQ17 / RHB5	JTC11394			
VQ18	JTC11167			

		
VQ22 / RHB5	JTC11297	
VQ4	JTC11192	
VQ5 / RHB6	JTC11393	
VQ50	JTC11729	
VQH15 / RHB5	JTC11297	
VR15	JTC11356	
VT10	JTC11593	
VV11	JTC11016	
VV13	JTC11016	
VV14	JTC11016	
VV16	JTC11500	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
VW19	JTC11016			
VVP2 / RHF3V	JTC11298			



*KKK*

1000 988 0005	JTC11643			
1000 988 0018	JTC11735			
1000 988 0019	JTC11720			
1000 988 0026	JTC11702			
1000 988 0027	JTC11703			
1000 988 0029	JTC11702			
1000 988 0052	JTC11702			
1000 988 0064	JTC11703			
1000 988 0065	JTC11702			
1000 988 0066	JTC11702			
1000 988 0102	JTC11702			

			<p>1855 988 0000</p>	<p>JTC11759</p>		
<p>5223 988 6001</p>	<p>JTC11039</p>		<p>OP10073 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10074 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10075 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10078 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10080 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10083 (SEE APPLICATION CATALOGUE BY MODEL)</p>			
<p>5230 988 4459</p>	<p>JTC11402</p>					
<p>5232 988 3270</p>	<p>JTC11269</p>					
<p>5232 988 3271</p>	<p>JTC11269</p>					
<p>5232 988 3272</p>	<p>JTC11269</p>					
<p>5232 988 3273</p>	<p>JTC11269</p>					

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

5232 988 3279	JTC11269			
5232 988 3286	JTC11432			
5232 988 3296	JTC11123			
5232 988 7410	JTC11267			
5303 988 0003	JTC11032			
5303 988 0005	JTC11018		OP10066	
5303 988 0006	JTC11019			
5303 988 0007	JTC11033			
5303 988 0009	JTC11149			
5303 988 0010	JTC11227			
5303 988 0011	JTC11262			

		
5303 988 0014	JTC11017	
5303 988 0015	JTC11251	
5303 988 0016	JTC11270	
5303 988 0017	JTC11270	
5303 988 0018	JTC11268	
5303 988 0019	JTC11180	
5303 988 0020	JTC11033	
5303 988 0022	JTC11018	
5303 988 0023	JTC11263	
5303 988 0024	JTC11263	
5303 988 0025	JTC11018	OP10065 



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

5303 988 0026	JTC11244			
5303 988 0028	JTC11227			
5303 988 0029	JTC11018		<p>OP10065 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10066 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10071 (SEE APPLICATION CATALOGUE BY MODEL)</p>	
5303 988 0034	JTC11204			
5303 988 0035	JTC11244			
5303 988 0036	JTC11401			
5303 988 0037	JTC11204			
5303 988 0038	JTC11017			
5303 988 0044	JTC11262			
5303 988 0045	JTC11262			

5303 988 0047	JTC11299			
5303 988 0048	JTC11030		<p>OP10095 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10096 (SEE APPLICATION CATALOGUE BY MODEL)</p>	
5303 988 0049	JTC11018		OP10070	
5303 988 0050	JTC11300			
5303 988 0051	JTC11300			
5303 988 0052	JTC11262			
5303 988 0053	JTC11244			
5303 988 0054	JTC11228			
5303 988 0055	JTC11240			
5303 988 0057	JTC11263			

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

5303 988 0058	JTC11244			
5303 988 0060	JTC11180			
5303 988 0061	JTC11268			
5303 988 0062	JTC11268			
5303 988 0063	JTC11149			
5303 988 0066	JTC11302		OP10117	
5303 988 0067	JTC11302		OP10116	
5303 988 0069	JTC11270			
5303 988 0070	JTC11270			
5303 988 0071	JTC11204			
5303 988 0073	JTC11018		OP10071	

		
5303 988 0075	JTC11204	
5303 988 0076	JTC11204	
5303 988 0078	JTC11302	OP10117 
5303 988 0081	JTC11228	
5303 988 0086	JTC11546	
5303 988 0087	JTC11531	
5303 988 0089	JTC11302	OP10117 
5303 988 0090	JTC11302	OP10116 
5303 988 0102	JTC11302	OP10117 
5303 988 0104	JTC11575	
5303 988 0105	JTC11546	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

5303 988 0106	JTC11531			
5303 988 0109	JTC11055		OP10060	
5303 988 0110	JTC11734			
5303 988 0114	JTC11302			
5303 988 0116	JTC11302		OP10116	
5303 988 0117	JTC11575			
5303 988 0118	JTC11575			
5303 988 0119	JTC11531			
5303 988 0120	JTC11575			
5303 988 0121	JTC11575			
5303 988 0122	JTC11767			

5303 988 0129	JTC11641	
5303 988 0130	JTC11576	
5303 988 0132	JTC11576	
5303 988 0133	JTC11601	
5303 988 0137	JTC11330	OP10064 
5303 988 0139	JTC11576	
5303 988 0140	JTC11601	
5303 988 0141	JTC11531	
5303 988 0144	JTC11767	
5303 988 0149	JTC11777	
5303 988 0151	JTC11602	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

5303 988 0163	JTC11575			
5303 988 0165	JTC11531			
5303 988 0169	JTC11576			
5303 988 0179	JTC11641			
5303 988 0181	JTC11575			
5303 988 0189	JTC11601			
5303 988 0190	JTC11601			
5303 988 0205	JTC11576			
5303 988 0207	JTC11330		OP10064	
5303 988 0217	JTC11641			
5303 988 0243	JTC11641			

		
5303 988 0248	JTC11602	
5303 988 0249	JTC11602	
5303 988 7000	JTC11636	
5303 988 7001	JTC11636	
5303 988 7200	JTC11629	
5304 988 0001	JTC11014	
5304 988 0002	JTC11034	
5304 988 0004	JTC11034	
5304 988 0006	JTC11034	
5304 988 0007	JTC11034	
5304 988 0008	JTC11034	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

5304 988 0011	JTC11215			
5304 988 0017	JTC11014			
5304 988 0020	JTC11303			
5304 988 0022	JTC11229			
5304 988 0023	JTC11303			
5304 988 0024	JTC11545			
5304 988 0025	JTC11270			
5304 988 0026	JTC11270			
5304 988 0029	JTC11577			
5304 988 0032	JTC11488			
5304 988 0033	JTC11523			

		
5304 988 0035	JTC11493	
5304 988 0043	JTC11493	
5304 988 0044	JTC11529	
5304 988 0045	JTC11493	
5304 988 0048	JTC11545	
5304 988 0049	JTC11545	
5304 988 0050	JTC11493	OP10125 
5304 988 0051	JTC11529	
5304 988 0052	JTC11571	
5304 988 0054	JTC11493	
5304 988 0055	JTC11529	OP10125 



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

5304 988 0057	JTC11555			
5304 988 0059	JTC11751			
5304 988 0062	JTC11350			
5304 988 0063	JTC11551			
5304 988 0064	JTC11546			
5304 988 0115	JTC11642			
5304 988 0184	JTC11751			
5304 988 9901	JTC11770			
5304 988 9905	JTC11770			
5306 988 0001	JTC11181			
5314 988 6000	JTC11002			

5314 988 6082	JTC11002	
5314 988 6085	JTC11002	
5314 988 6444	JTC11015	<p>OP10016 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10025 (SEE APPLICATION CATALOGUE BY MODEL)</p>
5314 988 6445	JTC11015	
5314 988 6446	JTC11015	
5314 988 6706	JTC11494	
5314 988 6707	JTC11248	
5314 988 6708	JTC11248	
5314 988 6709	JTC11248	
5314 988 7001	JTC11230	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

5314 988 7005	JTC11102			
5314 988 7009	JTC11002			
5314 988 7010	JTC11430			
5314 988 7014	JTC11002			
5314 988 7015	JTC11035			
5314 988 7016	JTC11222			
5314 988 7018	JTC11031			
5314 988 7020	JTC11230			
5314 988 7022	JTC11002			
5314 988 7024	JTC11215			
5314 988 7025	JTC11031			

				
5316 988 0016	JTC11727			
5316 988 0017	JTC11743			
5316 988 6000	JTC11096			
5316 988 6001	JTC11096			
5316 988 6003	JTC11013		OP10101	
5316 988 6004	JTC11128			
5316 988 6500	JTC11431			
5316 988 6700	JTC11271			
5316 988 6715	JTC11230			
5316 988 6721	JTC11248			
5316 988 6723	JTC11231			



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

5316 988 6733	JTC11304			
5316 988 6737	JTC11231			
5316 988 7016	JTC11372			
5316 988 7023	JTC11369			
5316 988 7024	JTC11369			
5316 988 7029	JTC11372			
5316 988 7030	JTC11372			
5316 988 7100	JTC11369			
5316 988 7108	JTC11369			
5316 988 7111	JTC11369			
5316 988 7114	JTC11372			

					
5316 988 7116	JTC11369				
5316 988 7118	JTC11369				
5316 988 7155	JTC11369				
5316 988 7156	JTC11369				
5316 990 7155	JTC11369				
5324 988 6010	JTC11305				
5324 988 6055	JTC11447				
5324 988 6080	JTC11150				
5324 988 6082	JTC11150				
5324 988 6206	JTC11041				
5324 988 6403	JTC11305				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

5324 988 6405	JTC11249			
5324 988 6406	JTC11495			
5324 988 6409	JTC11339			
5324 988 6417	JTC11447			
5324 988 6706	JTC11306			
5324 988 7000	JTC11370			
5324 988 7200	JTC11370			
5326 988 0000	JTC11726			
5326 988 1590	JTC11142			
5326 988 1591	JTC11142			
5326 988 1594	JTC11142			

		
5326 988 1597	JTC11142	
5326 988 6011	JTC11264	
5326 988 6012	JTC11264	
5326 988 6027	JTC11305	
5326 988 6031	JTC11128	
5326 988 6040	JTC11305	
5326 988 6084	JTC11305	
5326 988 6090	JTC11306	
5326 988 6091	JTC11307	
5326 988 6094	JTC11142	
5326 988 6201	JTC11049	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

5326 988 6202	JTC11049			
5326 988 6204	JTC11049			
5326 988 6205	JTC11049			
5326 988 6206	JTC11049			
5326 988 6290	JTC11306			
5326 988 6292	JTC11069			
5326 988 6482	JTC11429			
5326 988 6491	JTC11142			
5326 988 6492	JTC11142			
5326 988 6493	JTC11142			
5326 988 6494	JTC11142			

		
5326 988 6497	JTC11142	
5326 988 7200	JTC11142	
5327 988 5721	JTC11265	
5327 988 6001	JTC11039	
5327 988 6002	JTC11265	
5327 988 6010	JTC11265	
5327 988 6014	JTC11039	
5327 988 6015	JTC11039	
5327 988 6016	JTC11143	
5327 988 6017	JTC11265	
5327 988 6020	JTC11265	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

5327 988 6025	JTC11143		
5327 988 6032	JTC11265		
5327 988 6072	JTC11039		
5327 988 6205	JTC11265		
5327 988 6206	JTC11041		
5327 988 6207	JTC11052		
5327 988 6407	JTC11039		
5327 988 6409	JTC11265		
5327 988 6416	JTC11266		
5327 988 6425	JTC11010		
5327 988 6438	JTC11265		

			<p>5327 988 6441</p>	<p>JTC11039</p>		<p><b>OP10073</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10074</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10075</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10076</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10077</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10078</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10079</b> (SEE APPLICATION CATALOGUE BY MODEL)</p>	
<p>5327 988 6441</p>	<p>JTC11039</p>		<p><b>OP10080</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10083</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10085</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10086</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10087</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10088</b> (SEE APPLICATION CATALOGUE BY MODEL)</p>				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

5327 988 6444	JTC11039			
5327 988 6502	JTC11191			
5327 988 6507	JTC11041			
5327 988 6515	JTC11399			
5327 988 6520	JTC11318			
5327 988 6526	JTC11399			
5327 988 6533	JTC11041			
5327 988 6534	JTC11041			
5327 988 6607	JTC11265			
5327 988 6614	JTC11265			

<p>5327 988 6710</p>	<p>JTC11039</p> 	<p><b>OP10073</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10074</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10075</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10076</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10077</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10078</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10079</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> 
<p>5327 988 6710</p>	<p>JTC11039</p> 	<p><b>OP10080</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10083</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10085</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10086</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10087</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> <p><b>OP10088</b> (SEE APPLICATION CATALOGUE BY MODEL)</p> 



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

5327 988 6715	JTC11050			
5327 988 6718	JTC11039			
5327 988 6755	JTC11400			
5327 988 6796	JTC11233			
5327 988 6798	JTC11233			
5327 988 6800	JTC11232			
5327 988 6903	JTC11069			
5327 988 7008	JTC11265			
5327 988 7010	JTC11234			
5327 988 7014	JTC11265			
5327 988 7019	JTC11039			

					
5327 988 7024	JTC11052				
5327 988 7029	JTC11039				
5327 988 7096	JTC11039				
5327 988 7097	JTC11265				
5327 988 7101	JTC11383				
5327 988 7115	JTC11383				
5327 988 7121	JTC11579				
5327 988 7129	JTC11383				
5327 988 7130	JTC11383				
5327 988 7137	JTC11383				
5327 988 7141	JTC11579				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

5327 988 7192	JTC11383			
5327 988 7199	JTC11383			
5327 988 7200	JTC11400			
5327 988 7201	JTC11383			
5328 988 6410	JTC11373			
5328 988 6417	JTC11448			
5328 988 6800	JTC11054			
5328 988 7067	JTC11402			
5328 988 7083	JTC11207			
5329 988 6400	JTC11209			
5329 988 6705	JTC11209			

		
5329 988 6708	JTC11146	
5329 988 6711	JTC11496	
5329 988 7001	JTC11054	
5329 988 7005	JTC11076	
5329 988 7103	JTC11283	
5329 988 7105	JTC11051	
5329 988 7109	JTC11051	
5329 988 7112	JTC11051	
5329 988 7115	JTC11374	
5329 988 7116	JTC11374	
5329 988 7120	JTC11374	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

5329 988 7121	JTC11051			
5329 988 7122	JTC11588			
5329 988 7123	JTC11051			
5329 988 7130	JTC11051			
5331 980 7117	JTC11051			
5331 988 0010	JTC11051			
5331 988 6710	JTC11051			
5331 988 6711	JTC11496			
5331 988 6800	JTC11374			
5331 988 6902	JTC11051			
5331 988 6910	JTC11051			

		
5331 988 6911	JTC11418	
5331 988 7000	JTC11283	
5331 988 7117	JTC11051	
5331 988 7119	JTC11207	
5331 988 7137	JTC11418	
5331 988 7141	JTC11579	
5331 988 7200	JTC11404	
5331 988 7201	JTC11051	
5331 988 7206	JTC11051	
5331 988 7500	JTC11404	
5331 988 7507	JTC11579	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.



5331 988 7508	JTC11051			
5331 988 7508	JTC11579			
5333 988 6000	JTC11403			
5333 988 6406	JTC11123			
5333 988 6415	JTC11123			
5333 988 7001	JTC11403			
5336 988 6447	JTC11405			
5336 988 6456	JTC11269			
5336 988 6464	JTC11269			
5336 988 6467	JTC11405			
5336 988 6703	JTC11269			

					
5336 988 6707	JTC11269				
5336 988 6777	JTC11497				
5336 988 7024	JTC11269				
5431 988 0000	JTC11036				
5431 988 0002	JTC11036				
5431 988 0003	JTC11036				
5431 988 0005	JTC11036				
5435 971 0000	JTC11273				
5435 971 0002	JTC11273				
5435 971 0009	JTC11274				

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

			<p>5435 988 0000</p>	<p>JTC11273</p>		<p>OP10029 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10030 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10072 (SEE APPLICATION CATALOGUE BY MODEL)</p>	
<p>5435 988 0002</p>	<p>JTC11273</p>		<p>OP10029 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10030 (SEE APPLICATION CATALOGUE BY MODEL)</p>				
<p>5435 988 0005</p>	<p>JTC11250</p>		<p>OP10024 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10029 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10030 (SEE APPLICATION CATALOGUE BY MODEL)</p>				
<p>5435 988 0006</p>	<p>JTC11250</p>		<p>OP10002 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10003 (SEE APPLICATION CATALOGUE BY MODEL)</p> <p>OP10005 (SEE APPLICATION CATALOGUE BY MODEL)</p>				
<p>5435 988 0007</p>	<p>JTC11274</p>		<p>OP10014</p>				
<p>5435 988 0008</p>	<p>JTC11273</p>						

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
5435 988 0009	JTC11274		OP10014	
5435 988 0011	JTC11526		OP10072	
5435 988 0012	JTC11526			
5435 988 0014	JTC11481			
5435 988 0015	JTC11481			
5435 988 0018	JTC11580			
5435 988 0019	JTC11580			
5435 988 0021	JTC11274			
5435 988 0027	JTC11722			
5435 988 0029	JTC11526			
5435 988 0033	JTC11273			



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

5439 988 0002	JTC11465		OP10028	
5439 988 0005	JTC11020		OP10011 <small>(SEE APPLICATION CATALOGUE BY MODEL)</small>  OP10052 <small>(SEE APPLICATION CATALOGUE BY MODEL)</small>	
5439 988 0006	JTC11020		OP10001 <small>(SEE APPLICATION CATALOGUE BY MODEL)</small>  OP10051 <small>(SEE APPLICATION CATALOGUE BY MODEL)</small>  OP10052 <small>(SEE APPLICATION CATALOGUE BY MODEL)</small>	
5439 988 0007	JTC11020			
5439 988 0008	JTC11020			
5439 988 0009	JTC11378			
5439 988 0010	JTC11020			
5439 988 0011	JTC11378		OP10052	
5439 988 0012	JTC11020		OP10054	

5439 988 0015	JTC11371	
5439 988 0016	JTC11020	OP10052
5439 988 0017	JTC11020	OP10054 (SEE APPLICATION CATALOGUE BY MODEL)  OP10057 (SEE APPLICATION CATALOGUE BY MODEL)
5439 988 0018	JTC11020	
5439 988 0019	JTC11020	OP10052
5439 988 0020	JTC11378	OP10052
5439 988 0021	JTC11020	OP10051
5439 988 0022	JTC11378	OP10052
5439 988 0023	JTC11020	OP10054
5439 988 0024	JTC11020	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
All kits include the necessary components for one turbocharger.  
Scan QR code for a real picture of the product and technical tips.

5439 988 0026	JTC11020			
5439 988 0027	JTC11465		OP10028	
5439 988 0029	JTC11378		OP10061	
5439 988 0030	JTC11522		OP10018 <small>(SEE APPLICATION CATALOGUE BY MODEL)</small>  OP10072 <small>(SEE APPLICATION CATALOGUE BY MODEL)</small>  OP10091 <small>(SEE APPLICATION CATALOGUE BY MODEL)</small>	
5439 988 0045	JTC11726			
5439 988 0047	JTC11020		OP10001 <small>(SEE APPLICATION CATALOGUE BY MODEL)</small>  OP10051 <small>(SEE APPLICATION CATALOGUE BY MODEL)</small>  OP10052 <small>(SEE APPLICATION CATALOGUE BY MODEL)</small>	
5439 988 0048	JTC11540			
5439 988 0049	JTC11597			



		
5439 988 0053	JTC11525	
5439 988 0054	JTC11528	
5439 988 0055	JTC11525	
5439 988 0058	JTC11378	
5439 988 0059	JTC11525	
5439 988 0060	JTC11525	
5439 988 0065	JTC11725	
5439 988 0066	JTC11522	
5439 988 0067	JTC11482	
5439 988 0068	JTC11482	OP10061 

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

5439 988 0070	JTC11522		OP10018 (SEE APPLICATION CATALOGUE BY MODEL)  OP10072 (SEE APPLICATION CATALOGUE BY MODEL)  OP10091 (SEE APPLICATION CATALOGUE BY MODEL)	
5439 988 0071	JTC11540			
5439 988 0072	JTC11482		OP10061	
5439 988 0077	JTC11721			
5439 988 0080	JTC11522			
5439 988 0082	JTC11378			
5439 988 0083	JTC11020		OP10054	
5439 988 0085	JTC11378			
5439 988 0089	JTC11725			
5439 988 0097	JTC11378		OP10052	



				
5439 988 0098	JTC11620			
5439 988 0110	JTC11615			
5439 988 0111	JTC11638			
5439 988 0112	JTC11638			
5439 988 0114	JTC11620			
5439 988 0127	JTC11740			
5440 988 0002	JTC11620			
5440 988 0007	JTC11620			
5440 988 0021	JTC11620			



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.





Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
All kits include the necessary components for one turbocharger.  
Scan QR code for a real picture of the product and technical tips.



*mitsubishi*

			
28200-4A150	JTC11365		
28231-27000	JTC11331		
40173-06100	JTC11492		
47173-06503	JTC11040		
49130-01610	JTC11198		
49131-05060	JTC11637		
49131-05061	JTC11637		
49131-05101	JTC11379		
49131-05200	JTC11512		
49131-05210	JTC11512		OP10120 
49131-05212	JTC11512		

				
49131-05310	JTC11505		OP10130	
49131-05312	JTC11505		OP10130	
49131-05313	JTC11505		OP10130	
49131-06003	JTC11457		OP10002	
49131-06007	JTC11457		OP10002	
49131-07005	JTC11728			
49131-07008	JTC11728			
49131-07009	JTC11728			
49131-07015	JTC11728			
49131-07019	JTC11728			
49131-07030	JTC11728			



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
49131-07031	JTC11728			
49131-07040	JTC11728			
49131-07041	JTC11728			
49131-07050	JTC11728			
49135-00510	JTC11554			
49135-02110	JTC11196			
49135-02652	JTC11480			
49135-02682	JTC11480			
49135-03130	JTC11310			
49135-03300	JTC11291			
49135-03301	JTC11291			



		
49135-03410	JTC11553	
49135-03411	JTC11553	
49135-04121	JTC11196	
49135-04210	JTC11196	
49135-04211	JTC11196	
49135-04212	JTC11196	
49135-04302	JTC11196	
49135-04850	JTC11731	
49135-05000	JTC11015	
49135-05010	JTC11201	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

49135-05050	JTC11015		OP10016 (SEE APPLICATION CATALOGUE BY MODEL)  OP10025 (SEE APPLICATION CATALOGUE BY MODEL)	
49135-05131	JTC11302			
49135-05500	JTC11015			
49135-05670	JTC11026		OP10041	
49135-05671	JTC11026		OP10041	
49135-05710	JTC11026			
49135-05720	JTC11026			
49135-05730	JTC11026			
49135-05740	JTC11026			
49135-05750	JTC11026			



		
49135-05760	JTC11026	
49135-05761	JTC11026	
49135-05895	JTC11570	OP10121 
49135-06000	JTC11554	
49135-06010	JTC11554	
49135-06015	JTC11554	
49135-06017	JTC11554	
49135-06020	JTC11554	
49135-06025	JTC11554	
49135-06030	JTC11554	
49135-06035	JTC11554	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
49135-06037	JTC11554			
49135-07300	JTC11619			
49135-07302	JTC11619			
49135-07310	JTC11619			
49135-07311	JTC11619			
49135-07312	JTC11619			
49173-02010	JTC11640			
49173-02401	JTC11331			
49173-02412	JTC11331			
49173-02610	JTC11281			
49173-02702	JTC11765			

				
49173-06100	JTC11492			
49173-06101	JTC11492			
49173-06500	JTC11040			
49173-06501	JTC11040			
49173-07030	JTC11639			
49173-07300	JTC11199			
49173-07310	JTC11286			
49173-07502	JTC11351		OP10050	
49173-07504	JTC11351		OP10050	
49173-07506	JTC11351		OP10050	
49173-07507	JTC11351		OP10050	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
49173-07508	JTC11351		OP10013 (SEE APPLICATION CATALOGUE BY MODEL)  OP10050 (SEE APPLICATION CATALOGUE BY MODEL)	  
49173-07516	JTC11351		OP10050	
49173-07522	JTC11351		OP10050	
49173-07610	JTC11585			
49173-07615	JTC11585			
49173-07620	JTC11585			
49173-07621	JTC11585			
49177-01501	JTC11200			
49177-01503	JTC11200			
49177-01504	JTC11200			



		
49177-01505	JTC11200	
49177-01513	JTC11200	
49177-01515	JTC11200	
49177-02400	JTC11745	
49177-02410	JTC11745	
49177-02501	JTC11365	
49177-02512	JTC11196	
49177-02513	JTC11196	
49177-06400	JTC11026	OP10033 
49177-06410	JTC11026	OP10033 
49177-06422	JTC11026	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

49177-06430	JTC11026		OP10098	
49177-06432	JTC11026		OP10098	
49177-06452	JTC11026		OP10033	
49177-06572	JTC11026		OP10033	
49177-07612	JTC11196			
49177-90310	JTC11745			
49177-90410	JTC11745			
49177-91210	JTC11747			
49177-92702	JTC11747			
49178-01010	JTC11750			
49178-01510	JTC11200			

		
49178-01940	JTC11749	
49184-02000	JTC11178	
49189-01000	JTC11261	
49189-01300	JTC11261	
49189-01310	JTC11381	
49189-01360	JTC11381	
49189-01365	JTC11381	
49189-01370	JTC11381	
49189-01375	JTC11381	
49189-01700	JTC11009	
49189-05201	JTC11411	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
49335-01100	JTC11748			
49335-01101	JTC11748			
49373-01001	JTC11603			
49373-01004	JTC11603			
49373-01005	JTC11603			
49373-02002	JTC11635			
49373-02003	JTC11635			
49373-03012	JTC11776			
49377-00500	JTC11537			
49377-00510	JTC11554			
49377-03040	JTC11553			



					
49377-03041	JTC11553				
49377-03043	JTC11553				
49377-04300	JTC11367				
49377-06000	JTC11450				
49377-06010	JTC11450				
49377-06150	JTC11742				
49377-06160	JTC11742				
49377-06161	JTC11742				
49377-06200	JTC11381				
49377-06201	JTC11381				
49377-06202	JTC11381				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

49377-06203	JTC11381			
49377-06204	JTC11381			
49377-06210	JTC11381			
49377-06211	JTC11381			
49377-06212	JTC11381			
49377-06213	JTC11381			
49377-06511	JTC11381			
49377-07000	JTC11204			
49377-07010	JTC11346			
49377-07050	JTC11038			
49377-07052	JTC11038			



					
49377-07300	JTC11524				
49377-07301	JTC11524				
49377-07303	JTC11524				
49377-07311	JTC11524				
49377-07400	JTC11598				
49377-07401	JTC11598				
49377-07402	JTC11598				
49377-07403	JTC11598				
49377-07404	JTC11598				
49377-07405	JTC11598				
49377-07406	JTC11598				

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

			
49377-07420	JTC11598		
49377-07421	JTC11598		
49377-07423	JTC11598		
49377-07424	JTC11598		
49377-07426	JTC11598		
49377-07440	JTC11598		
49377-07460	JTC11598		
49377-07530	JTC11598		
49378-01580	JTC11595		
49378-01641	JTC11595		
49477-01202	JTC11775		

					
49477-01203	JTC11775				
49477-01213	JTC11775				
49477-02003	JTC11788				
49477-02004	JTC11788				
49477-02005	JTC11788				
49477-02051	JTC11788				
49S31-05210	JTC11038				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.





Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
All kits include the necessary components for one turbocharger.  
Scan QR code for a real picture of the product and technical tips.



*SCHWITZER*

149955	JTC11141			
166592	JTC11178			
169190	JTC11076			
172149	JTC11039			
181819	JTC11538			
310006	JTC11172			
310130	JTC11173			
310134	JTC11173			
310135	JTC11173			
310407	JTC11064			
310677	JTC11176			



					
310794	JTC11115				
311170	JTC11172				
311297	JTC11265				
311500	JTC11092				
311510	JTC11128				
312172	JTC11178				
312208	JTC11179				
312209	JTC11070				
312214	JTC11416				
312227	JTC11172				
312243	JTC11172				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
312246	JTC11176			
312256	JTC11064			
312257	JTC11123			
312261	JTC11050			
312283	JTC11182			
312311	JTC11050			
312319	JTC11183			
312320	JTC11265			
312650	JTC11198			
312682	JTC11054			
312730	JTC11128			



					
312731	JTC11404				
312779	JTC11404				
312787	JTC11209				
312862	JTC11184				
312917	JTC11405				
312926	JTC11335				
312934	JTC11015				
312939	JTC11070				
313050	JTC11039				
313191	JTC11185				
313216	JTC11186				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
313275	JTC11479			
313352	JTC11050			
313414	JTC11054			
313418	JTC11186			
313425	JTC11039			
313503	JTC11305			
313505	JTC11305			
313614	JTC11187			
313624	JTC11065			
313913	JTC11064			
313951	JTC11404			



		
314001	JTC11265	
314044	JTC11265	
314071	JTC11151	
314469	JTC11051	
314522	JTC11187	
315002	JTC11417	
315195	JTC11404	
315543	JTC11404	
315550	JTC11051	
315626	JTC11209	
315705	JTC11187	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.



				
315730	JTC11123			
315926	JTC11052			
315953	JTC11054			
315998	JTC11052			
316045	JTC11385			
316302	JTC11404			
316308	JTC11404			
316310	JTC11404			
316468	JTC11157			
316480	JTC11123			
316504	JTC11305			



					
316699	JTC11418				
316752	JTC11151				
316756	JTC11054				
316775	JTC11265				
317454	JTC11588				
317476	JTC11588				
317673	JTC11404				
317755	JTC11151				
317817	JTC11187				
317959	JTC11479				
317960	JTC11479				

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.



				
317980	JTC11088			
318168	JTC11088			
318295	JTC11051			
318418	JTC11169			
318419	JTC11174			
318420	JTC11175			
318421	JTC11177			
318442	JTC11502			
318960	JTC11418			
319261	JTC11587			



*TOYOTA*

			
17201-0L020	JTC11218		
17201-0L030	JTC11218		
17201-0L040	JTC11452		
17201-0R040	JTC11543		
17201-17010	JTC11164		
17201-17030	JTC11165		
17201-17040	JTC11161		
17201-17070	JTC11586		
17201-26031	JTC11543		
17201-26051	JTC11543		
17201-27030	JTC11435		



					
17201-27040	JTC11435				
17201-27050	JTC11718				
17201-30010	JTC11611				
17201-30011	JTC11611				
17201-30030	JTC11610				
17201-30040	JTC11218				
17201-30100	JTC11452				
17201-30160	JTC11452				
17201-33010	JTC11221				
17201-33020	JTC11221				
17201-42020	JTC11164				



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
17201-54030	JTC11063			
17201-54060	JTC11163			
17201-54090	JTC11453			
17201-64030	JTC11162			
17201-64110	JTC11161			
17201-64170	JTC11162			
17201-67010	JTC11413			
17201-68010	JTC11166			
17201-74030	JTC11164			
17201-74080	JTC11705			
2439500	JTC11164			

		
2439502	JTC11165	
2439504	JTC11164	
2439506	JTC11063	
2439508	JTC11163	
2439510	JTC11161	
2439512	JTC11413	
2439514	JTC11166	
2439516	JTC11164	
2439520	JTC11161	
2439522	JTC11162	
2439523	JTC11162	



Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

				
2439524	JTC11162			
2439525	JTC11161			
2439528	JTC11203			
2439529	JTC11164			
2439530	JTC11221			
2439531	JTC11218			
2439531	JTC11452			
2439535	JTC11162			
2439536	JTC11162			
2439537	JTC11161			
2439538	JTC11451			

					
2439543	JTC11162				
2439544	JTC11453				
2439547	JTC11063				
2439548	JTC11162				
2439550	JTC11452				
2439553	JTC11454				
2439554	JTC11454				
2439557	JTC11218				
2439558	JTC11218				
2439559	JTC11162				
2439561	JTC11221				

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.

2439565	JTC11063			
B	JTC11453			
BITURBO CT12	JTC11454			
C	JTC11162			
CT12	JTC11161			
CT12	JTC11162			
CT12A	JTC11451			
CT12-I	JTC11162			
CT20	JTC11063			
CT20	JTC11203			
CT20	JTC11412			

					
CT26	JTC11164		CT9	JTC11161	
CT9	JTC11162		D	JTC11162	

Replace gaskets, studs, nuts and oil feed pipe when installing a new turbocharger.  
 All kits include the necessary components for one turbocharger.  
 Scan QR code for a real picture of the product and technical tips.